

S&W V-NOTCHED REAR SIGHT KITS - BROWNELLS S&W J FRAME .122 V-NOTCH SIGHT KIT

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

Complete Rear Sight Replacement Kit

Complete rear sight kit replaces the standard blade on your Smith & Wesson revolver and provides a wide, V-shaped notch. Enables faster pick up of the front sight, especially with fine bead and ball front sights. Adjustable for windage. Some "J" frame models may use a smaller head diameter. The screw in this kit has a .217" diameter head.



Attributes

- Name: [BROWNELLS S&W J FRAME .122 V-NOTCH SIGHT KIT](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078003002
- Mfr. No.:
- Model: Universal Handguns
- Sight Color: Black
- Style: V-Notch
- Weapon type: Smith & Wesson
- Delivery weight: 0.005kg
- Shipping height: 10mm
- Shipping width: 102mm
- Shipping length: 137mm
- UPC: 050806004313

Item details

Made in USA

Table of Contents

- Startpage
- S&W VNotched Rear Sight Kits Safety Instruction Guide
- About Us

S&W VNotched Rear Sight Kits Safety Instruction Guide

Introduction

Thank you for choosing the S&W VNotched Rear Sight Kit. This guide provides essential safety information and instructions for the installation and use of your new rear sight kit. Please read this manual carefully to ensure safe and proper use.

General Safety Guidelines

- Ensure the product is suitable for your specific model of Smith & Wesson revolver.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Keep the rear sight kit out of reach of children and unauthorized users.
- Inspect the kit for any damage before installation. Do not use if any parts are damaged.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

• Potential Hazards:

- Improper installation may lead to misalignment, affecting accuracy.
- Using the wrong blade height may result in improper sighting.

• Avoiding Hazards:

- Follow installation instructions carefully to ensure proper alignment.
- Ensure the diameter of the screw matches your firearm's specifications.

• Age Specific Warnings:

- This product is intended for adult use only. Keep away from children.

Instructions for Installation and Usage

• Installation:

1. Ensure your firearm is unloaded and pointed in a safe direction.
2. Remove the existing rear sight blade from your Smith & Wesson revolver.
3. Select the appropriate blade height for your model:
 - .122" for Jframe only
 - .160" & .196" for K, L, and Nframe
4. Insert the new sight blade into the rear sight housing.
5. Secure the sight blade using the windage screw, ensuring it is tightened appropriately.
6. Adjust for windage as necessary to align with your front sight.

• Usage:

- Familiarize yourself with the new sighting system before live firing.
- Practice aiming with the new Vnotched sight to improve accuracy.
- Regularly check the tightness of the sight components to ensure they remain secure.

Disposal Instructions

- Dispose of any damaged or unused components in accordance with local regulations.
- Do not dispose of in regular household waste. Check for local recycling programs or hazardous waste disposal facilities.

Contact Information for Further Support

For any inquiries regarding the S&W VNotched Rear Sight Kit, please refer to your local dealer or manufacturer's website for assistance.

Thank you for prioritizing safety and following these guidelines. Enjoy your enhanced shooting experience with the S&W VNotched Rear Sight Kit!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk