

# AR-15/M16 EXTRACTOR BUFFER - EXTRACTOR BUFFERS, 10-PAK

[Home](#)

## Stronger Base For Eliminating Extractor Bounce

Tough, dense rubber insert replaces factory buffer inside the extractor spring to prevent extractor bounce that can occur in rapid-fire conditions. Insert keeps the extractor from losing contact with casings and reducing faulty ejection of the spent casing. Sold in 10-paks.



## Attributes

- Name: [EXTRACTOR BUFFERS, 10-PAK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000071
- Mfr. No.:
- Make: AR-15
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- AR15/M16 Extractor Buffer Safety Instructions
- About Us

# AR15/M16 Extractor Buffer Safety Instructions

## Introduction

Thank you for choosing the AR15/M16 Extractor Buffer. This product is designed to enhance the performance of your firearm by preventing extractor bounce during rapidfire conditions. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

## General Safety Guidelines

- Always handle firearms with care and follow all safety protocols.
- Ensure that the firearm is unloaded before performing any maintenance or installation.
- Store the extractor buffer in a cool, dry place away from direct sunlight.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the extractor buffer for wear or damage before each use.

## Specific Safety Precautions for Use

- Do not exceed the manufacturer's recommended rate of fire as this may lead to excessive wear on the extractor buffer.
- Ensure that the extractor buffer is properly installed before using your firearm.
- If you experience any malfunction or unusual behavior from your firearm after installation, cease use immediately and consult a qualified gunsmith.
- Avoid using the product with ammunition that is not suitable for your firearm.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, which may include a punch tool and a hammer.

### 2. Installation:

- Remove the extractor spring from the firearm.
- Carefully remove the factory buffer from the extractor spring.
- Insert the new AR15/M16 Extractor Buffer into the extractor spring.
- Reassemble the extractor spring and ensure that the buffer is securely in place.

### 3. Usage:

- After installation, test the firearm in a controlled environment to ensure proper function.
- Monitor the performance of the extractor buffer during use, checking for any signs of malfunction.

## Disposal Instructions

- Dispose of any worn or damaged extractor buffers in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal options.

## Contact Information for Further Support

For any questions or concerns regarding the AR15/M16 Extractor Buffer, please reach out to the manufacturer through their official contact channels. Ensure that you have the product details ready for assistance.

By following these guidelines, you can ensure safe and effective use of your AR15/M16 Extractor Buffer. Thank you for prioritizing safety and performance in your firearm usage.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)