

AR-15 TRIGGER GUARD ASSEMBLY - BROWNELLS BRN AR-15 TRIGGER GUARD ASSEMBLY, 5.56MM

[Rifle Parts](#) > [Triggers Parts](#) > [Trigger Guards](#)

Replacement Trigger Guard Assembly for standard AR-15s.



Attributes

- Name: [BROWNELLS BRN AR-15 TRIGGER GUARD ASSEMBLY, 5.56MM](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000527
- Mfr. No.:
- Finish: Black
- Weapon type: AR-15
- Delivery weight: 0.002kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 102mm
- UPC: 050806003859

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- AR15 Trigger Guard Assembly Safety Instructions
- About Us

AR15 Trigger Guard Assembly Safety Instructions

Introduction

Thank you for choosing the AR15 Trigger Guard Assembly from BROWNELLS. This product is designed to enhance the safety and functionality of your AR15 firearm. Please read this safety instruction guide carefully to ensure proper use and handling.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep firearms out of the reach of children and unauthorized users.
- Use appropriate protective gear, including eye and ear protection, when handling firearms.
- Ensure that the firearm is pointed in a safe direction at all times.
- Regularly inspect your firearm and its components for wear and damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that the trigger guard assembly is compatible with your AR15 model before installation.
- Do not modify the trigger guard assembly in any way.
- Always ensure the firearm is unloaded before installing or removing components.
- Avoid using the firearm in wet or humid conditions to prevent corrosion of metal parts.
- Be aware of your surroundings and ensure that no one is in the line of fire when handling the firearm.
- If you notice any unusual sounds or malfunctions during use, stop immediately and inspect the firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded.
- Gather necessary tools, including a screwdriver and any other required tools as per manufacturer specifications.

2. Installation Steps

- Remove the existing trigger guard assembly from the AR15 by unscrewing the retaining screws.
- Align the new AR15 Trigger Guard Assembly with the mounting points on the firearm.
- Secure the assembly by tightening the screws, ensuring it is firmly in place but not overtightened.

3. PostInstallation Checks

- After installation, perform a function check to ensure the trigger guard assembly is properly installed.
- Check for any movement or instability in the assembly.

4. Usage Instructions

- When using the firearm, ensure that the trigger guard assembly is clean and free of debris.
- Regularly inspect the assembly for signs of wear or damage.

Disposal Instructions

- Dispose of the product in accordance with local regulations.

- If the trigger guard assembly is damaged or no longer in use, do not throw it in regular trash. Instead, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's official website or customer service channels.

By following these safety instructions, you help ensure a safer experience while using your AR15 Trigger Guard Assembly. Always prioritize safety and responsibility when handling firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk