

YOKE/CRANE ALIGNMENT TOOL - BROWNELLS #1 YOKE/CRANE ALIGNMENT TOOL FOR S&W J FRAME

[Gunsmith Tools](#) > [Handgun Tools](#) > [Crane Tools](#)

.0005" Tolerances For Ultimate Accuracy

Because both Ruger® and S&W's lock at the front and rear of the extractor rod, even a slightly bent one can cause difficulty in lockup and will impair smooth operation, especially for double-action shooting. These tools will enable the gunsmith to more easily and precisely align the crane in a matter of minutes without "guesswork". Precision ground and hardened to within .0005" on all critical dimensions to assure the ultimate in accuracy. Full instructions with each tool. Hardened to Rc 52-54 to maintain exact specs.



Attributes

- Name: [BROWNELLS #1 YOKE/CRANE ALIGNMENT TOOL FOR S&W J FRAME](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080616001
- Mfr. No.:
- Model: J Frame
- Weapon type: Smith & Wesson
- Delivery weight: 0.018kg
- Shipping height: 10mm
- Shipping width: 86mm
- Shipping length: 170mm
- UPC: 050806019317

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [YOKE/CRANE ALIGNMENT TOOL SAFETY INSTRUCTIONS](#)
- [About Us](#)

YOKE/CRANE ALIGNMENT TOOL SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the YOKE/CRANE ALIGNMENT TOOL, specifically designed for the Smith & Wesson J Frame. This tool is essential for precise alignment of the crane, ensuring smooth operation of your firearm. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always read and understand all instructions before using the YOKE/CRANE ALIGNMENT TOOL.
- Ensure that the tool is used only for its intended purpose as described in the product specifications.
- Keep the tool out of reach of children and unauthorized users.
- Inspect the tool for any damage or wear before each use. Do not use if damaged.
- Follow all local laws and regulations regarding firearm maintenance and safety.

Specific Safety Precautions for Use

- Use the tool in a welllit and clean environment to avoid accidents.
- Wear appropriate safety gear, such as safety glasses, to protect your eyes from debris.
- Do not force the tool into position; apply gentle pressure to avoid damaging your firearm.
- Ensure that the firearm is unloaded and in a safe condition before using the alignment tool.
- Avoid contact with moving parts during operation to prevent injury.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather all necessary tools and materials, including the YOKE/CRANE ALIGNMENT TOOL.

2. Aligning the Crane

- Insert the YOKE/CRANE ALIGNMENT TOOL into the crane of the firearm.
- Gently adjust the tool until the crane is aligned properly.
- Check alignment visually and by feel, ensuring that there is no resistance when moving the crane.

3. Locking Mechanism Check

- After alignment, check the locking mechanism of the extractor rod to ensure it engages smoothly.
- If resistance is felt, recheck the alignment and adjust as necessary.

4. Final Inspection

- After use, remove the alignment tool and inspect the crane and extractor rod for proper function.
- Ensure that all components are secure and functioning correctly before using the firearm.

Disposal Instructions

- Dispose of the YOKE/CRANE ALIGNMENT TOOL in accordance with local regulations.
- If the tool is damaged beyond repair, consider recycling materials where applicable.

Contact Information for Further Support

For any safety inquiries or concerns regarding the YOKE/CRANE ALIGNMENT TOOL, please refer to the relevant EU-based contact point or consult your local firearms expert.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the YOKE/CRANE ALIGNMENT TOOL. Always prioritize safety and compliance with local laws when handling firearms and tools. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk