

YOKER/CRANE REAMER FOR RUGER & S&W REVOLVERS

[Gunsmith Tools & Supplies](#) > [Handgun Tools](#) > [Crane Tools](#)

Frees-Up Ejector Springs; Restores I.D. Dimension

Removes all burrs and roughness from inside the Ruger® "Six" Series D.A. and S&W K/L/N crane. Also restores crane to proper dimensions after "stretching" to eliminate endshake.



Attributes

- Name: [YOKER/CRANE REAMER FOR RUGER & S&W REVOLVERS](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080627000
- Mfr. No.:
- Make: Ruger,Smith & Wesson
- Model: K Frame,L Frame,N Frame,Security Six,Service Six,Single Six,Speed Six
- Delivery weight: 0.068kg
- Shipping height: 3mm
- Shipping width: 86mm
- Shipping length: 216mm
- UPC: 050806104044

Item details

Made in USA

Table of Contents

- Startpage
- YOKE/CRANE REAMER Safety Instruction Guide
- About Us

YOKE/CRANE REAMER Safety Instruction Guide

Introduction

Thank you for purchasing the YOKE/CRANE REAMER designed for Ruger and Smith & Wesson revolvers. This tool is engineered to remove burrs and roughness from the inside of the Ruger "Six" Series D.A. and S&W K/L/N crane, while also restoring the crane to its proper dimensions. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure the tool is used only for its intended purpose as outlined in this guide.
- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, while using the tool.
- Keep the tool out of reach of children and unauthorized users.
- Inspect the tool for any signs of damage or wear before each use. Do not use if damaged.
- Follow all local regulations regarding the use and disposal of tools.

Specific Safety Precautions for Use

- Use the YOKE/CRANE REAMER only on the specified models: Ruger Security Six, Service Six, Single Six, Speed Six, and Smith & Wesson K Frame, L Frame, N Frame.
- Ensure the revolver is unloaded and clear of any ammunition before using the reamer.
- Do not force the tool; apply consistent and gentle pressure for best results.
- Be aware of sharp edges on the tool. Handle with care to avoid cuts or injuries.
- Store the tool in a secure location when not in use to prevent accidents.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the revolver is completely unloaded.
- Gather all necessary tools and safety equipment.

2. Using the YOKE/CRANE REAMER:

- Carefully insert the reamer into the crane of the revolver.
- Apply gentle pressure while rotating the reamer to remove burrs and roughness.
- Check the crane's dimensions periodically to ensure proper restoration.
- After use, clean the tool to remove any debris and store it safely.

3. PostUse Inspection:

- Inspect the reamer for any signs of wear or damage after each use.
- Replace the tool if any defects are found to ensure safe operation in the future.

Disposal Instructions

- Dispose of the YOKE/CRANE REAMER in accordance with local regulations.
- If the tool is damaged beyond repair, ensure it is disposed of in a manner that prevents accidental injury to others.

Contact Information for Further Support

For any safety inquiries or concerns regarding the YOKE/CRANE REAMER, please contact your local dealer or manufacturer. Ensure you have the product details ready for a more effective response.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your YOKE/CRANE REAMER. Always prioritize safety and compliance with local regulations while using this tool. Thank you for your attention to these important guidelines.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at