

1911 MAINSPRING CAP PIN - MAINSPRING CAP PIN FOR 1911, BLUED,6 PACK

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Cap Pins](#)

U.S.-Made Parts For The 1911 Auto Pistol

Each and every part is U.S.-made, high-quality and guaranteed to fit and function just like the factory part.



Attributes

- Name: [MAINSPRING CAP PIN FOR 1911, BLUED,6 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 100000879
- Mfr. No.:
- Finish: Blued
- Make: 1911
- Model: Commander, Government, Officers
- Delivery weight: 0.045kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806029316

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Mainspring Cap Pin
- About Us

Safety Instruction Guide for 1911 Mainspring Cap Pin

Introduction

Thank you for purchasing the 1911 Mainspring Cap Pin. This product is designed to enhance the performance and reliability of your 1911 firearm. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Store firearms and ammunition separately and securely.
- Wear appropriate eye and ear protection when handling firearms.
- Familiarize yourself with the specific model of your firearm before installation.
- Follow all local laws and regulations regarding firearms.

Specific Safety Precautions for Use

- **Potential Hazards:** Improper installation or use may lead to malfunction or injury.
- **Avoiding Hazards:**
 - Ensure that the firearm is unloaded before performing any maintenance or installation.
 - Use only the specified parts for your firearm model (Government, Commander, Officers).
 - Do not modify the mainspring cap pin or any other components.
- **Age Restrictions:** This product is intended for adult use only. Keep out of reach of children.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation (e.g., screwdriver, punch).

2. Installation Process:

- Remove the old mainspring cap pin by following the manufacturer's instructions for disassembly.
- Insert the new 1911 Mainspring Cap Pin into the designated slot.
- Ensure it is seated properly and secured according to the firearm's specifications.

3. PostInstallation Check:

- After installation, perform a function check of the firearm to ensure proper operation.
- If you notice any unusual behavior, consult a qualified gunsmith.

4. Usage:

- Regularly inspect the mainspring cap pin for wear and tear.
- Replace the part if any damage is detected.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.

- Do not dispose of parts in regular household waste. Contact local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please consult the manufacturer's contact point in the EU. Ensure you have your product information ready for assistance.

By following these guidelines, you can ensure safe and effective use of the 1911 Mainspring Cap Pin. Thank you for prioritizing safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at