

EXTRACTOR DEPRESSOR PLUNGER SPRING - EXTRACTOR DEP. PLUNGER SPRING

[Handgun Parts](#) > [Action Parts](#) > [Extractor Parts](#) > [Extractor Springs](#)

Extractor Depressor Plunger Spring - fits all models Gen3 & Gen4 except the G-42 and G-43.



Attributes

- Name: [EXTRACTOR DEP. PLUNGER SPRING](#)
- Manufacturer: [GLOCK](#)
- Product no.: 100002683
- Mfr. No.:
- Make: Glock
- Model: Universal Handguns
- Delivery weight: 0.005kg
- Shipping width: 57mm
- Shipping length: 89mm

Table of Contents

- Startpage
- Safety Instruction Guide for Extractor Depressor Plunger Spring
- About Us

Safety Instruction Guide for Extractor Depressor Plunger Spring

Introduction

Thank you for choosing the Extractor Depressor Plunger Spring designed for Glock Universal Handguns. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before use.

General Safety Guidelines

- Always ensure that the product is suitable for your specific handgun model. This spring fits all models Gen3 & Gen4 except the G42 and G43.
- Inspect the product for any visible damage or defects before installation. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Ensure that all safety precautions are followed during installation and use to minimize risks.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Use appropriate protective gear (e.g., safety glasses) when handling the product.
- Never attempt to modify or alter the spring as this may compromise its safety and functionality.
- Ensure that the firearm is unloaded before installing or replacing the spring.
- Be cautious of spring tension during installation and removal to avoid injury.
- Follow all manufacturer guidelines for your specific handgun model to ensure compatibility and safety.

Instructions for Installation and Usage

1. Preparation

- Ensure that your handgun is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (if required).

2. Installation Steps

- Remove the slide from the handgun according to the manufacturer's instructions.
- Locate the existing extractor depressor plunger spring. Carefully remove it using appropriate tools.
- Take the new Extractor Depressor Plunger Spring and ensure it is positioned correctly.
- Install the new spring by reversing the removal process, ensuring it is seated properly.
- Reassemble the handgun as per the manufacturer's guidelines.

3. Usage

- After installation, perform a function check to ensure the spring operates correctly.
- Regularly inspect the spring for wear and tear during routine maintenance of your handgun.

Disposal Instructions

- Dispose of the product in accordance with local regulations for firearm accessories.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding the safety or functionality of the Extractor Depressor Plunger Spring, please refer to your retailer or the manufacturer's website for support.

Thank you for prioritizing safety and compliance while using the Extractor Depressor Plunger Spring. Your adherence to these guidelines helps ensure a safe experience.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at