

# SLIDE RELEASE FOR GLOCK® - GHOST BULLET FORWARD SLIDE RELEASE

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

## Larger Contact Pad for Better Control & Faster Operation

Ghost's Bullet Slide Release (BSR) for Glock® is an extended control that helps you engage in fast, positive operation of the slide release under stress. The biggest benefit of the BSR is its oversized control pad because a larger surface is easier to hit, making release of the slide possible even when your finger doesn't come down square on the button. The Ghost Bullet Slide Release's extra-large control pad is contoured and streamlined so it does not present an extra risk for snagging on clothing or other gear during a draw from holster. Ruggedly built to stand up to hard use Stainless steel with matte black finish that blends with slide & frame Left-handed friendly - easier to operate with the index finger when firing left handed Standard & Forward BSR fit these Glock® Gen1 thru Gen4 models: 17 (three-pin only), 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 37, 38, 39, 40 & 41. DOES NOT work on Gen5 models Separate BSR model for Glock® 42 and 43 Ghost developed the Bullet FORWARD version of the BSR for shooters using the modern "thumbs forward" shooting technique. The Bullet Forward Slide Release has the control pad moved forward, thus getting it out of the way so your thumbs do not accidentally push the release UP while shooting and lock the slide open before the mag is empty. If your thumb stance is a little different, it will also help keep you from accidentally pulling the release DOWN and preventing the slide from locking open on the last round. All versions of Ghost's Bullet Slide Release are easy to install in your Glock®. They drop right into your pistol, replacing the factory release with no other permanent modifications to the gun.



## Attributes

- Name: [GHOST BULLET FORWARD SLIDE RELEASE](#)
- Manufacturer: [GHOST](#)
- Product no.: 100009415
- Mfr. No.: GHO\_BFS\_BLK
- Caliber: 38/357 Caliber (.357-.359), 9 mm (.355-.356), 40/10 mm (.400-.401), 45 Caliber (.451-.454)
- Finish: Black
- Model: 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 37, 38, 39
- Weapon type: Glock
- Delivery weight: 0.011kg
- Shipping height: 18mm
- Shipping width: 64mm
- Shipping length: 107mm
- UPC: 644406721055

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for the SLIDE RELEASE FOR GLOCK® GHOST BULLET FORWARD SLIDE RELEASE
- About Us

# Safety Instruction Guide for the SLIDE RELEASE FOR GLOCK® GHOST BULLET FORWARD SLIDE RELEASE

## Introduction

Thank you for choosing the Ghost Bullet Slide Release (BSR) for your Glock®. This product is designed to enhance the operation of your firearm, allowing for a faster and more positive engagement of the slide release. However, it is important to use this product safely and responsibly. This guide provides essential safety instructions and guidelines to help you use the product effectively while ensuring compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Ensure that the product is compatible with your specific Glock® model. The BSR fits Glock® Gen1 through Gen4 models, excluding Gen5 and is also available for Glock® 42 and 43.
- Always treat your firearm as if it is loaded, even when it is not.
- Keep the firearm pointed in a safe direction at all times.
- Store the firearm and accessories in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the BSR for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm use and ownership.

## Specific Safety Precautions for Use

- Use the BSR only as intended. The Bullet Forward Slide Release is designed for shooters using the modern "thumbs forward" shooting technique.
- Be aware that the oversized control pad is designed to facilitate operation under stress, but ensure that your grip does not inadvertently engage the slide release during shooting.
- If you are lefthanded, practice operating the BSR to ensure familiarity and comfort with the control pad's positioning.
- Avoid wearing loose clothing that may snag on the BSR during the draw from the holster.
- Always ensure that the firearm is unloaded before attempting to install or remove the BSR.

## Instructions for Installation and Usage

### Installation Instructions

1. **Safety First:** Ensure that your Glock® is unloaded. Remove the magazine and visually inspect the chamber.
2. **Remove the Factory Slide Release:** Using a suitable tool, carefully remove the factory slide release from your Glock®.
3. **Install the Ghost BSR:** Align the Ghost Bullet Slide Release with the designated slot in your Glock® and gently press it into place until it clicks securely.
4. **Check Functionality:** After installation, check to ensure that the BSR operates smoothly and engages the slide release as intended.
5. **Reassemble Your Firearm:** Once the installation is complete, reassemble your Glock® and perform a function check.

### Usage Instructions

- Grip your firearm with a stable stance, ensuring that your fingers are positioned correctly.
- When ready to engage the slide release, use your index finger to press the oversized control pad firmly.
- Practice using the BSR in a safe environment to become familiar with its operation and to mitigate any

risk of accidental engagement.

- Always maintain focus on your target and surroundings while handling your firearm.

## Disposal Instructions

- Dispose of the Ghost Bullet Slide Release in accordance with local regulations regarding electronic and metal waste.
- Do not dispose of the product in regular household waste. Check for recycling options in your area.

## Contact Information for Further Support

For questions or concerns regarding the Ghost Bullet Slide Release, please refer to the manufacturer's website or contact your local dealer for assistance. Always ensure that you have access to reliable information regarding safety and product usage.

By following these guidelines and instructions, you can ensure the safe and effective use of the Ghost Bullet Slide Release for your Glock®. Stay informed about product recalls and safety updates through the EU's Safety Gate platform. Your safety and the safety of others is of utmost importance.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)