

SLIDE RELEASE FOR GLOCK® - GHOST BULLET SLIDE RELEASE

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

Larger Contact Pad for Better Control & Faster Operation

Ghost's Bullet Slide Release (BSR) for Glock® is an extended control that helps you engage in fast, positive operation of the slide release under stress. The biggest benefit of the BSR is its oversized control pad because a larger surface is easier to hit, making release of the slide possible even when your finger doesn't come down square on the button. The Ghost Bullet Slide Release's extra-large control pad is contoured and streamlined so it does not present an extra risk for snagging on clothing or other gear during a draw from holster. Ruggedly built to stand up to hard use Stainless steel with matte black finish that blends with slide & frame Left-handed friendly - easier to operate with the index finger when firing left handed Standard & Forward BSR fit these Glock® Gen1 thru Gen4 models: 17 (three-pin only), 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 37, 38, 39, 40 & 41. DOES NOT work on Gen5 models Separate BSR model for Glock® 42 and 43 Ghost developed the Bullet FORWARD version of the BSR for shooters using the modern "thumbs forward" shooting technique. The Bullet Forward Slide Release has the control pad moved forward, thus getting it out of the way so your thumbs do not accidentally push the release UP while shooting and lock the slide open before the mag is empty. If your thumb stance is a little different, it will also help keep you from accidentally pulling the release DOWN and preventing the slide from locking open on the last round. All versions of Ghost's Bullet Slide Release are easy to install in your Glock®. They drop right into your pistol, replacing the factory release with no other permanent modifications to the gun.



Attributes

- Name: [GHOST BULLET SLIDE RELEASE](#)
- Manufacturer: [GHOST](#)
- Product no.: 100009416
- Mfr. No.: GHO_BSR_BLK
- Caliber: 38/357 Caliber (.357-.359), 9 mm (.355-.356), 40/10 mm (.400-.401), 45 Caliber (.451-.454)
- Finish: Black
- Model: 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 37, 38, 39
- Weapon type: Glock
- Delivery weight: 0.011kg
- Shipping height: 18mm
- Shipping width: 66mm
- Shipping length: 107mm
- UPC: 644406731054

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for SLIDE RELEASE FOR GLOCK® GHOST BULLET SLIDE RELEASE
- About Us

Safety Instruction Guide for SLIDE RELEASE FOR GLOCK® GHOST BULLET SLIDE RELEASE

Introduction

Thank you for choosing the Ghost Bullet Slide Release (BSR) for your Glock® firearm. This guide provides essential safety instructions to ensure the safe and effective use of the product, in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before installation and use.

General Safety Guidelines

- **Product Safety:** The Ghost Bullet Slide Release is designed to enhance the safety and performance of your Glock® firearm. Ensure you understand the product's functionality before use.
- **Enhanced Recalls:** In the unlikely event of a product recall, you will receive standardized notifications and remedies at no cost.
- **Online Shopping:** If purchased online, you are entitled to the same safety protections as when buying in physical stores.
- **Special Consumer Focus:** This product is not intended for children. Keep it out of reach of minors.
- **EU Contact Point:** For any safety inquiries, please refer to the EU contact point listed on the packaging or product documentation.
- **Rapid Alerts:** Stay informed about product safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Installation Safety:** Ensure the firearm is unloaded before installing the Bullet Slide Release.
- **Finger Placement:** Be mindful of finger placement when operating the slide release to avoid accidental discharge.
- **Training:** Familiarize yourself with the operation of the slide release in a controlled environment before using it in highstress situations.
- **Regular Inspection:** Periodically inspect the slide release for wear or damage. Replace if any issues are detected.
- **Holster Compatibility:** Ensure that your holster is compatible with the extended slide release to prevent snagging.

Instructions for Installation and Usage

1. Installation:

- Ensure your Glock® is unloaded and pointed in a safe direction.
- Remove the factory slide release by following the manufacturer's guidelines.
- Insert the Ghost Bullet Slide Release into the designated slot until it clicks into place.
- Verify that the release is secure and functions properly before use.

2. Usage:

- When engaging the slide release, use the oversized control pad for a positive engagement.
- Practice the operation of the slide release in a safe environment to ensure familiarity.
- If using the Bullet Forward version, adjust your grip to avoid accidental engagement during shooting.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding firearm accessories.
- Do not throw away in regular household waste. Instead, check for designated recycling or hazardous waste disposal facilities.

Contact Information for Further Support

For any further inquiries regarding the Ghost Bullet Slide Release, please consult the product packaging or documentation for the appropriate contact details.

Thank you for your attention to these safety instructions. Your safety and the safe operation of your firearm are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk