

PRO TRIGGER CONNECTOR FOR GLOCK® 42/43/43X/48 - GHOST

PRO TRIGGER CONNECTOR FOR GLOCK 42/43/43X/48

[Handgun Parts](#) > [Trigger Group Parts](#) > [Connector Parts](#)

The GHOST G42/G43 PRO is the best self-defense & Target trigger control connector Ghost makes! The G42/G43 PRO is Smoother, Lighter, Shorter and eliminates trigger Over-travel! These attributes give you the fastest most accurate first shot hit advantage of any self-defense Glock style trigger. HIT FIRST & FAST WITH THE PRO The G42/G43 PRO fixes the Glock “bump” or glitch, this is the pre-travel resistance you feel and must overcome when the trigger bar “bumps” into the connector. This “bump” causes you to apply excessive force and will move the pistol off target. Another thing the G42/G43 PRO corrects is trigger over-travel; the excessive movement of the trigger after the pistol fires. Over-travel causes the pistol to move off of alignment with the target, making your shot go low and to one side. G42/G43 PRO KEEPS YOU ON TARGET The G42/G43 PRO is the best self-defense connector made! We believe that this trigger control connector makes all others obsolete. Once you try it, we know you will agree! Minor fitting required. This Connector is For CCW Self-Defense. Recommended: A gunsmith or armorer should install this connector. PLEASE NOTE : THIS IS NOT A DROP IN TRIGGER CONNECTOR. Small flat Swiss file needed.



Attributes

- Name: [GHOST PRO TRIGGER CONNECTOR FOR GLOCK 42/43/43X/48](#)
- Manufacturer: [GHOST](#)
- Product no.: 100017680
- Mfr. No.: GHO_42-43-2424-
- Model: 42,43,43X,48
- Weapon type: Glock
- Delivery weight: 0.011kg
- Shipping height: 25mm
- Shipping width: 64mm
- Shipping length: 127mm
- UPC: 813978020013

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [PRO TRIGGER CONNECTOR FOR GLOCK® 42/43/43X/48 Safety Instruction Guide](#)
- [About Us](#)

PRO TRIGGER CONNECTOR FOR GLOCK®

42/43/43X/48 Safety Instruction Guide

Introduction

Thank you for choosing the PRO TRIGGER CONNECTOR FOR GLOCK® 42/43/43X/48 by GHOST. This safety instruction guide provides essential information for the safe use, installation, and disposal of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product to ensure your safety and the safety of others.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the PRO TRIGGER CONNECTOR as it is designed for nonfood products. Follow all safety instructions to minimize risks.
- **Enhanced Recalls:** Stay informed about product recalls. If the connector is found to be dangerous, you will be notified through standardized recall notices.
- **Online Shopping:** When purchasing online, ensure that the retailer complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** This product is intended for responsible adults. Extra caution should be taken to keep it out of reach of children.
- **EU Contact Point:** For any safety inquiries, refer to the designated EU contact point associated with this product.
- **Rapid Alerts:** Be aware of the Safety Gate system for faster updates on unsafe products.

Specific Safety Precautions for Use

- **Installation Warning:** Minor fitting is required. It is highly recommended that a qualified gunsmith or armorer install the connector. This is not a drop-in trigger connector.
- **Trigger OverTravel:** Ensure that you understand the concept of trigger overtravel and how the connector helps to minimize it. Improper installation may lead to unsafe firearm operation.
- **Handling:** Always treat your firearm as if it is loaded. Ensure that the firearm is pointed in a safe direction when handling.
- **Testing:** Once installed, test the trigger system in a safe environment to ensure proper functionality before using it in a livefire situation.
- **Excessive Force:** Avoid applying excessive force when operating the trigger, as this may lead to loss of control and misalignment with the target.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is unloaded and pointed in a safe direction.
- Have a small flat Swiss file ready for minor fitting.

2. Installation Steps:

- Remove the slide from the Glock pistol.
- Carefully remove the existing connector from the trigger assembly.
- Install the PRO TRIGGER CONNECTOR by aligning it properly with the trigger bar.
- Use the small flat Swiss file to make any necessary minor adjustments for a proper fit.
- Reassemble the firearm, ensuring all components are secure.

3. Usage:

- Familiarize yourself with the new trigger feel before engaging in livefire practice.
- Regularly inspect the connector for wear and proper function.
- If you experience any issues, consult a qualified gunsmith or armorer for assistance.

Disposal Instructions

- Dispose of the PRO TRIGGER CONNECTOR responsibly. Do not dispose of it with regular household waste.
- If the product is damaged or no longer in use, consider returning it to a qualified firearms dealer or following local regulations for hazardous waste disposal.

Contact Information for Further Support

For any questions or concerns regarding the PRO TRIGGER CONNECTOR, please refer to the designated EU contact point or consult with a qualified gunsmith or armorer.

By following these safety instructions, you can ensure the safe and effective use of the PRO TRIGGER CONNECTOR FOR GLOCK® 42/43/43X/48. Always prioritize safety and responsibility when handling firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk