

# **FIRING PIN SPRING CUPS - KE ARMS FIRING PIN SPRING CUPS, PAIR**

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Hardware](#)

Aftermarket Glock spring cups. 1 pair. Made in the USA.



## **Attributes**

- Name: [KE ARMS FIRING PIN SPRING CUPS, PAIR](#)
- Manufacturer: [KE ARMS](#)
- Product no.: 100023131
- Mfr. No.: 1-50-25-003
- Model: 22,34,23,26,32,19,37,27,31,17,33
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 51mm
- Shipping length: 127mm

## **Item details**

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for FIRING PIN SPRING CUPS by KE ARMS
- About Us

# Safety Instruction Guide for FIRING PIN SPRING CUPS by KE ARMS

## Introduction

Thank you for choosing the FIRING PIN SPRING CUPS by KE ARMS. This product has been designed to enhance the performance of your Glock firearm. To ensure safe and effective use, please read this safety instruction guide carefully. It contains important information regarding safety, installation, and usage.

## General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure that you are in a safe environment when installing or using the firing pin spring cups.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for signs of wear or damage.
- Follow all local laws and regulations regarding firearm modifications and usage.
- Report any unsafe products or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- Only use the FIRING PIN SPRING CUPS with compatible Glock models as specified: 37, 17, 19, 22, 23, 34, 26, 27, 31, 32, 33.
- Ensure that the firearm is unloaded before beginning installation.
- Wear appropriate safety gear, such as safety glasses, during installation.
- Do not attempt to modify the firing pin spring cups or any other firearm components.
- If you experience any malfunctions or issues after installation, cease use immediately and consult a qualified gunsmith.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and any other required equipment.

### 2. Installation:

- Remove the slide from the Glock firearm according to the manufacturer's instructions.
- Locate the firing pin assembly within the slide.
- Carefully remove the existing spring cups from the firing pin assembly.
- Install the new FIRING PIN SPRING CUPS by KE ARMS in the same position as the original cups.
- Reassemble the slide and ensure all components are securely in place.

### 3. Usage:

- After installation, conduct a function check to ensure the firearm operates correctly.
- Test the firearm in a safe and controlled environment, following all safety protocols.
- Always follow the manufacturer's guidelines for operating the firearm.

## Disposal Instructions

- Dispose of any old or damaged firing pin spring cups in accordance with local regulations.
- Do not throw away the product in regular household waste. Instead, take it to a designated recycling or

hazardous waste facility.

## **Contact Information for Further Support**

For safety inquiries or assistance regarding the FIRING PIN SPRING CUPS, please contact your local KE ARMS representative or visit the official KE ARMS website for more information.

Thank you for your attention to these safety instructions. Your safety and the safety of others is our top priority. Please use this product responsibly and in compliance with all applicable laws and regulations.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)