

VICTORY TRIGGER FOR THE SW22 VICTORY - TANDEMROSS "VICTORY" TRIGGER FOR THE SW22 VICTORY - BLACK - TEXTURED

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Triggers](#)

At a glance: Flat-faced, skeletonized design for better control and feel. Textured trigger face offers a no-slip grip in any condition. 100% adjustable for pre-travel and post-travel. Can drop trigger pull weight up to $\frac{1}{2}$ a pound. The factory SW22® Victory™ trigger stands out in the rimfire market for its crisp feel and light trigger pull. But even good triggers can be made GREAT! The new TANDEMROSS "Victory" Trigger for the Smith & Wesson SW22® Victory™ is the ultimate SW22® trigger upgrade - ideal for speed shooting competitors! The TANDEMROSS "Victory" Trigger removes nearly all pre-travel upon installation, and comes with pre- and post-travel adjustment screws to allow each shooter customize their SW22® trigger upgrade. The skeletonized, lightweight design of the TANDEMROSS "Victory" trigger provides a flat face that allows the shooter to pull straight back and makes it easier to tell if they are pulling too far to the left or right. In addition to actually reducing the trigger pull weight by up to .5lbs, the flat-faced design also allows the operator to place their finger lower on the trigger, increasing leverage and giving the perception of an even lower pull weight. The textured SW22® trigger provides a no-slip surface regardless of speed or weather and allows for short, repeatable, identical trigger pulls. The trigger is made from aircraft-grade aluminum to be lightweight and durable. The TANDEMROSS "Victory" Trigger for SW22® Victory™ is one of the best SW22® upgrades for competition shooters. Get yours today and take a giant step closer to VICTORY!



Attributes

- Name: [TANDEMROSS "VICTORY" TRIGGER FOR THE SW22 VICTORY - BLACK - TEXTURED](#)
- Manufacturer: [TANDEMROSS](#)
- Product no.: 100023269
- Mfr. No.: TK23N0113BLK1
- Finish: Black
- Model: Victory 22
- Style: Flat
- Weapon type: Smith & Wesson
- Delivery weight: 0.011kg
- Shipping height: 25mm
- Shipping width: 76mm
- Shipping length: 108mm
- UPC: 769498487648

Item details

Made in USA
US export classification: 0A501.c

Table of Contents

- Startpage
- VICTORY TRIGGER FOR THE SW22 VICTORY SAFETY INSTRUCTIONS
- About Us

VICTORY TRIGGER FOR THE SW22 VICTORY SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the TANDEMROSS "Victory" Trigger for the Smith & Wesson SW22® Victory™. This product is designed to enhance your shooting experience while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use, install, and dispose of the trigger safely.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following guidelines:

- Always treat every firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Ensure the firearm is pointed in a safe direction at all times.
- Be aware of your surroundings and ensure a clear shooting area.
- Use appropriate protective gear, including eye and ear protection, when shooting.
- Regularly inspect your firearm and accessories for signs of wear or damage.
- Store firearms and ammunition securely and out of reach of children.

Specific Safety Precautions for Use

When using the TANDEMROSS "Victory" Trigger, please observe the following precautions:

- Ensure that the firearm is unloaded before installing or adjusting the trigger.
- Do not attempt to modify the trigger beyond the manufacturer's specifications.
- Be cautious of the trigger pull weight adjustment; excessive reduction may lead to accidental discharges.
- Avoid using the trigger in adverse weather conditions that may affect grip or control.
- If you experience any malfunctions or irregularities, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

To ensure safe and effective use of the TANDEMROSS "Victory" Trigger, follow these instructions carefully:

Installation

1. **Prepare the Firearm:** Ensure the SW22® Victory™ is unloaded and pointed in a safe direction.
2. **Remove the Factory Trigger:** Follow the manufacturer's instructions for disassembling the trigger mechanism.
3. **Install the "Victory" Trigger:**
 - Align the TANDEMROSS "Victory" Trigger with the trigger mechanism.
 - Securely fasten the trigger in place according to the manufacturer's specifications.
4. **Adjust Pre and Post Travel:**
 - Use the provided adjustment screws to customize the trigger's pre and post travel to your preference.
 - Test the trigger pull weight and adjust as necessary, ensuring it remains within safe limits.

Usage

- Before each use, conduct a safety check to ensure the trigger is functioning correctly.
- Familiarize yourself with the trigger's feel and responsiveness before engaging in live shooting.
- Practice dry firing in a safe environment to build confidence and control.

Disposal Instructions

When it is time to dispose of the TANDEMROSS "Victory" Trigger, please follow these guidelines:

- Do not dispose of the trigger in regular household waste.
- Check local regulations for proper disposal of firearm accessories.
- If the trigger is damaged or no longer functional, consider recycling the metal components where possible.

Contact Information for Further Support

For questions or concerns regarding the TANDEMROSS "Victory" Trigger, please refer to the contact information provided on the packaging or the manufacturer's website.

By adhering to these safety instructions, you can ensure a safe and enjoyable shooting experience with your TANDEMROSS "Victory" Trigger for the SW22® Victory™. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk