

GUIDE ROD ASSEMBLY FOR GLOCK® 17 - RIVAL ARMS GUIDE ROD ASSEMBLY GLOCK 17 GEN 3, STAINLESS

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Experienced shooters realize plastic guide rods can chip, crack, or break resulting in feeding or ejection failures, flex can also contribute to accuracy problems. Rival Arms™ Guide Rod Assemblies address all of these issues and will provide you a lifetime of reliable service.



Attributes

- Name: [RIVAL ARMS GUIDE ROD ASSEMBLY GLOCK 17 GEN 3, STAINLESS](#)
- Manufacturer: [RIVAL ARMS](#)
- Product no.: 100038495
- Mfr. No.: RA-RA50G101S
- Model: 17,Gen 3
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 114mm
- UPC: 788130027080

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for GUIDE ROD ASSEMBLY FOR GLOCK® 17 RIVAL ARMS
- About Us

Safety Instruction Guide for GUIDE ROD ASSEMBLY FOR GLOCK® 17 RIVAL ARMS

Introduction

Thank you for purchasing the Rival Arms™ Guide Rod Assembly for Glock® 17 Gen 3. This product is designed for experienced shooters seeking improved reliability and performance. Please read this safety instruction guide carefully to ensure safe use and compliance with EU regulations.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms with care and ensure they are pointed in a safe direction.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the guide rod assembly for signs of wear or damage.
- In case of any doubts regarding safety, consult a qualified gunsmith or firearms expert.

Specific Safety Precautions for Use

- Avoid using the guide rod assembly with incompatible models or modifications.
- Ensure that all components are properly installed before use.
- Do not exceed the manufacturer's recommended specifications for ammunition.
- Be aware of the potential hazards associated with improper installation, including feeding or ejection failures.
- Maintain a safe distance from others when testing the firearm with the new guide rod assembly.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool and a cleaning cloth.

2. Installation

- Remove the slide from the frame of the Glock® 17.
- Use the punch tool to carefully remove the existing guide rod assembly.
- Clean the area to remove any debris or residue.
- Insert the Rival Arms™ Guide Rod Assembly into the slide, ensuring it is seated properly.
- Reassemble the slide onto the frame and perform a function check to ensure smooth operation.

3. Usage

- Always conduct a function check before using the firearm.
- Use appropriate ammunition as specified by the firearm manufacturer.
- Regularly clean and maintain the guide rod assembly to ensure optimal performance.

Disposal Instructions

- Dispose of the guide rod assembly in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options if available in your area.

Contact Information for Further Support

For safety inquiries or further assistance regarding the Rival Arms™ Guide Rod Assembly, please refer to the product packaging for the EUbased contact information.

Conclusion

Following these safety instructions will help ensure a safe and enjoyable experience with your Rival Arms™ Guide Rod Assembly for Glock® 17 Gen 3. Always prioritize safety and consult with professionals when necessary. Thank you for choosing Rival Arms™ .

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk