

AR-15 EXTRACTOR SPRING O-RING - BROWNELL'S BRN AR-15 BOLT EXTRACTOR SPRING O-RING, BLACK

[Home](#)

OEM AR-15/M16 replacement Extractor O-Ring.



Attributes

- Name: [BROWNELL'S BRN AR-15 BOLT EXTRACTOR SPRING O-RING, BLACK](#)
- Manufacturer: [BROWNELL'S](#)
- Product no.: 100040955
- Mfr. No.: AZ-0005
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029606

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Extractor Spring ORing
- About Us

Safety Instruction Guide for AR15 Extractor Spring ORing

Introduction

Thank you for choosing the AR15 Extractor Spring ORing by Brownells. This guide provides important safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified in this guide.
- Always handle the product with care to avoid injury or damage.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for signs of wear or damage before use.
- In case of any malfunction or damage, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Use only with compatible AR15/M16 systems as specified by the manufacturer.
- Avoid using excessive force during installation to prevent damage to the ORing or surrounding components.
- Do not expose the ORing to extreme temperatures or harsh chemicals that may degrade its material.
- Ensure that the ORing is properly seated in the extractor before use to prevent malfunctions.
- If you notice any unusual performance or signs of wear, consult a qualified gunsmith for inspection.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is unloaded and in a safe condition before starting the installation.
- Gather necessary tools, such as a punch tool and a small screwdriver.

2. Installation Steps

- Remove the existing extractor from the bolt assembly.
- Carefully remove the old ORing from the extractor.
- Place the new AR15 Extractor Spring ORing onto the extractor, ensuring it fits snugly.
- Reinstall the extractor back into the bolt assembly, ensuring it is properly secured.

3. Usage

- After installation, perform a function check to ensure the extractor operates smoothly.
- Store the firearm in a secure location when not in use.
- Follow all local laws and regulations regarding the use of firearms.

Disposal Instructions

- Dispose of any damaged or worn ORings in accordance with local waste disposal regulations.
- Do not incinerate the ORing as it may release harmful substances.

Contact Information for Further Support

- For any safety inquiries or further assistance, please refer to the contact information provided by the manufacturer or retailer.

Thank you for your attention to these safety guidelines. Your safety and the proper functioning of your equipment are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk