

# EDGE BAG GATER - EDGEWOOD SHOOTING BAGS EDGE BAG GATER TALL 4"H 3/8" SPREAD 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

This is a long, heavy bag - about twice the length of the Original (6" x 13") - the ultimate in stability. Filled weight can easily top 25 lbs. depending on body height. It features a padded top for resting the trigger hand and includes the same choices of ear combination as the Original. The Gater has a multi-layered all flat base. EDGE model includes the following upgrades: Extra rigid, super flat bag base made with a unique material resists deformation over time ""Overlay Ears"" - Whether you choose slick material or cordura, a durable layer of leather is added underneath the material which contributes to consistency in shape and performance as well as extreme longevity and resistance to wear. Flatter ear space means the riding surface at the base of the ears has been redesigned to practically eliminate inconsistencies in the transition between the riding surface and the ear base. This remedies any potential drag or grabbing and increases longevity by removing an inherent wear point. Reinforced ear base isolates the ear set from the shape of the bag, contributing to consistency in the contact surface and ear spread. Embroidered cordura tops showcase our brand new logo and highlight the evolution of our designs.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGE BAG GATER TALL 4"H 3/8" SPREAD 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045563
- Mfr. No.: EDGE TALL GATER
- Colour: Black/ Tan
- Material: 3M Slick,Leather
- Style: Rabbit,Rear Bag
- Delivery weight: 0.59kg
- Shipping height: 127mm
- Shipping width: 178mm
- Shipping length: 330mm

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [Safety Instructions for EDGE BAG GATER EDGEWOOD SHOOTING BAGS](#)
- [About Us](#)

# Safety Instructions for EDGE BAG GATER EDGEWOOD SHOOTING BAGS

## Introduction

Thank you for choosing the EDGE BAG GATER EDGEWOOD SHOOTING BAGS. This guide provides essential safety information to ensure the safe and effective use of your shooting bag. Please read this document carefully before use.

## General Safety Guidelines

- Ensure that the shooting bag is used only for its intended purpose.
- Always inspect the bag for any signs of damage or wear before use.
- Keep the bag out of reach of children and vulnerable individuals when not in use.
- Use the bag in a safe environment, away from potential hazards such as firearms not being handled safely.
- Familiarize yourself with the features of the bag to ensure proper usage.
- Follow all local laws and regulations related to shooting and firearm safety.

## Specific Safety Precautions for Use

- **Weight Consideration:** The filled weight of the bag can exceed 25 lbs. Ensure that you can handle the weight safely to avoid injury.
- **Padded Top Usage:** Always use the padded top for resting your trigger hand to prevent fatigue and ensure stability.
- **Ear Combination:** Choose the appropriate ear combination based on your shooting style and preferences.
- **Surface Stability:** Ensure the bag is placed on a stable surface to prevent slipping or tipping during use.
- **Avoid Overloading:** Do not exceed the recommended weight limit for the bag to maintain its integrity and performance.
- **Proper Handling:** When lifting or moving the bag, bend your knees and lift with your legs to avoid back strain.

## Instructions for Installation and Usage

### 1. Setting Up the Bag:

- Place the bag on a flat, stable surface before use.
- Ensure that the multilayered flat base is fully in contact with the ground for maximum stability.

### 2. Filling the Bag:

- If filling the bag, ensure that the weight is evenly distributed to maintain balance.
- Use only recommended materials for filling to avoid compromising the bag's structure.

### 3. Using the Padded Top:

- Rest your trigger hand on the padded top when aiming to enhance comfort and control.
- Adjust your position as necessary to maintain a stable shooting stance.

### 4. After Use:

- Clean the bag according to the manufacturer's instructions to ensure longevity.

- Store the bag in a cool, dry place away from direct sunlight to prevent material degradation.

## **Disposal Instructions**

- Dispose of the bag according to local regulations regarding plastic and textile waste.
- If the bag is damaged beyond repair, consider recycling the materials if possible.
- Do not dispose of the bag in regular household waste if it contains hazardous materials.

## **Contact Information for Further Support**

For any inquiries regarding safety or product issues, please refer to the manufacturer's website or contact customer service through the provided channels.

By following these safety instructions, you can ensure a safe and enjoyable experience with your EDGEBAG GATER EDGEWOOD SHOOTING BAGS. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)