

EDGEWOOD NEW FARLEY FRONT BAGS - EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT REST 3" VARMINT 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Edgewood New Farley front bags. Available in 2-1/4" or 3".



Attributes

- Name: [EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT REST 3" VARMINT 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045617
- Mfr. No.: NEW FARLEY 3 IN
- Colour: Black/ Tan
- Material: Leather,3M Slick
- Style: Rest Top,Front Bag
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Edgewood New Farley Front Bags
- About Us

Safety Instruction Guide for Edgewood New Farley Front Bags

Introduction

Thank you for choosing the Edgewood New Farley Front Bags. These bags are designed to enhance your shooting experience while ensuring safety and reliability. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always handle the Edgewood New Farley Front Bags with care to prevent accidents.
- Ensure that the bags are used only for their intended purpose as a shooting rest.
- Keep the product out of reach of children and vulnerable individuals to avoid misuse.
- Regularly inspect the bags for any signs of wear or damage before each use.
- Follow all local laws and regulations regarding the use of shooting equipment.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - The bags can become slippery when wet; avoid using them in wet conditions.
 - Ensure the bags are stable before placing any firearms on them.
- **Avoiding Hazards:**
 - Use the bags only on stable and level surfaces to prevent tipping.
 - Do not overload the bags beyond their intended capacity.
 - Ensure that all firearms are unloaded when not in use.
- **Audience Specific Warnings:**
 - This product is not intended for children under the age of 18.
 - Ensure that inexperienced users are supervised by a qualified adult when using the bags.

Instructions for Installation and Usage

- **Installation:**
 - Place the Edgewood New Farley Front Bag on a stable shooting platform or bench.
 - Ensure that the bag is positioned securely and will not move during use.
- **Usage:**
 - Position your firearm securely on the front bag.
 - Adjust the height of the bag (if applicable) to achieve a comfortable shooting position.
 - Always maintain control of your firearm and ensure it is pointed in a safe direction.
 - After use, remove the firearm from the bag and store it safely.

Disposal Instructions

- Dispose of the Edgewood New Farley Front Bags responsibly when they are no longer usable.
- Check local regulations for the proper disposal of leather and synthetic materials.
- Do not incinerate the bags as they may release harmful substances when burned.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Edgewood New Farley Front Bags, please refer to the manufacturer's contact points provided on the packaging or product documentation.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe

and enjoyable shooting experience with your Edgewood New Farley Front Bags.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk