

EDGEWOOD NEW FARLEY FRONT BAGS - EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT REST 3" VARMINT W/REINFORCED TOP 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Edgewood New Farley front bags. Available in 2-1/4" or 3".



Attributes

- Name: [EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT REST 3" VARMINT W/REINFORCED TOP 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045619
- Mfr. No.: NEW FARLEY 3 IN
- Colour: Black/ Tan
- Material: Leather,3M Slick
- Style: Rest Top,Front Bag
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for EDGEWOOD New Farley Front Bags
- About Us

Safety Instruction Guide for EDGEWOOD New Farley Front Bags

Introduction

Thank you for choosing the EDGEWOOD New Farley Front Bags. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this document carefully before using the bags to understand the safety precautions and proper usage.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as a shooting bag.
- Regularly inspect the bags for any signs of wear and tear before each use.
- Keep the bags out of reach of children and pets to prevent accidents.
- Always follow local laws and regulations regarding the use of shooting equipment.
- In case of product damage or malfunction, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

• Hazard Identification:

- The bags may contain small parts that could pose a choking hazard if disassembled.
- The use of shooting bags involves handling firearms, which can be dangerous if not managed properly.

• Avoiding Hazards:

- Always ensure that the firearm is unloaded when setting up or adjusting the bags.
- Use the bags on stable surfaces to prevent tipping or sliding.
- Never place your hands or body in front of the firearm when using the bags.
- Wear appropriate eye and ear protection when using firearms in conjunction with the bags.

• Age Specific Warnings:

- This product is not intended for use by children under 18 years of age without adult supervision.
- Ensure that inexperienced users are guided by a knowledgeable adult when handling firearms and shooting bags.

Instructions for Installation and Usage

• Installation:

- Place the EDGEWOOD New Farley Front Bag on a stable, flat surface.
- Ensure that the bag is positioned securely before placing any equipment on it.

• Usage:

- Adjust the height of the bag as needed to achieve a comfortable shooting position.
- Position the firearm securely on top of the bag, ensuring it is stable and balanced.
- Use the bag to support the front of the firearm for improved accuracy during shooting.
- After use, carefully remove the firearm from the bag and store it safely.

Disposal Instructions

- Dispose of any damaged or worn bags in accordance with local waste disposal regulations.
- Consider recycling materials where possible, such as leather and synthetic components.
- Do not burn the bags as they may release harmful substances.

Contact Information for Further Support

For any safety inquiries or concerns regarding the EDGEWOOD New Farley Front Bags, please refer to the designated EU contact point for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with the EDGEWOOD New Farley Front Bags. Always prioritize safety and responsibility when using shooting equipment. Thank you for your attention to these guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk