

EDGEWOOD NEW FARLEY FRONT BAGS - EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT 2-1/4" HUNTER W/REINFORCED TOP 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Edgewood New Farley front bags. Available in 2-1/4" or 3".



Attributes

- Name: [EDGEWOOD SHOOTING BAGS NEW FARLEY FRONT 2-1/4" HUNTER W/REINFORCED TOP 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045620
- Mfr. No.: NEW FARLEY 2 1/
- Colour: Black/ Tan
- Material: 3M Slick,Leather
- Style: Front Bag,Rest Top
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for EDGEWOOD New Farley Front Bags
- About Us

Safety Instruction Guide for EDGEWOOD New Farley Front Bags

Introduction

Thank you for choosing the EDGEWOOD New Farley Front Bags. This guide provides important safety information to ensure the safe use and handling of this product. Please read and follow these instructions carefully to avoid any potential hazards.

General Safety Guidelines

- Always inspect the product before use for any signs of damage or wear.
- Keep the product out of reach of children and vulnerable individuals.
- Ensure that the product is used only for its intended purpose.
- Follow all local regulations regarding the use of shooting bags.
- In case of any doubts or questions, refer to the contact information provided in this guide.

Specific Safety Precautions for Use

- **Handling:**
 - Always handle the bag with care to avoid any injury.
 - Use gloves if the material feels uncomfortable against your skin.
- **Storage:**
 - Store the bag in a dry, cool place to prevent deterioration of materials.
 - Avoid storing the bag in direct sunlight for prolonged periods.
- **Usage:**
 - Ensure a stable shooting platform when using the bag.
 - Do not exceed the recommended weight limits for the bag.
- **Cleaning:**
 - Clean the bag with a damp cloth and mild soap if necessary.
 - Do not use harsh chemicals or abrasive materials that may damage the bag.

Instructions for Installation and Usage

1. **Setup:**
 - Place the EDGEWOOD New Farley Front Bag on a stable surface.
 - Ensure that the bag is positioned securely before placing any equipment on it.
2. **Usage:**
 - Rest your firearm on the bag for support during shooting.
 - Adjust the positioning of the bag as needed for optimal stability.
3. **PostUse Care:**
 - After use, check the bag for any signs of wear or damage.
 - Store the bag properly to maintain its condition.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the bag is damaged beyond repair, consider recycling the materials if possible.
- Do not dispose of the bag in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the EDGEWOOD New Farley Front Bags, please refer to the manufacturer's contact information provided with your product.

Conclusion

Following these safety guidelines will help ensure a safe and enjoyable experience with your EDGEWOOD New Farley Front Bags. Always prioritize safety and adhere to local regulations when using the product. Thank you for your attention to these important instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk