

STANDARD BOLT KNOB - CHRISTENSEN ARMS STANDARD BOLT KNOB

[Rifle Parts](#) > [Bolt Parts](#) > [Charging Handle Parts](#) > [Charging Handles](#)

Replacement bolt knob found on Christensen Arms hunting rifles. Features a laser-etched Rams Head logo. Specifications: Found on standard Christensen Arms rifles Replacement Bolt Knob Features laser-etched Rams Head logo



Attributes

- Name: [CHRISTENSEN ARMS STANDARD BOLT KNOB](#)
- Manufacturer: [CHRISTENSEN ARMS](#)
- Product no.: 100050210
- Mfr. No.: 810-00019-01
- Finish: Black
- Model: 700
- Style: Lightweight
- Weapon type: Remington
- Delivery weight: 0.023kg
- UPC: 691328232695

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for STANDARD BOLT KNOB CHRISTENSEN ARMS](#)
- [About Us](#)

Safety Instruction Guide for STANDARD BOLT KNOB CHRISTENSEN ARMS

Introduction

Thank you for choosing the STANDARD BOLT KNOB from Christensen Arms. This product is designed to enhance your hunting rifle experience. Please read this safety instruction guide carefully to ensure safe and effective use of the bolt knob.

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or handling the bolt knob.
- Store the bolt knob in a secure location, out of reach of children and unauthorized users.
- Inspect the bolt knob for any signs of damage or wear before use. Do not use if damaged.
- Follow all relevant firearm safety guidelines when using your hunting rifle.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper installation may lead to malfunction of the firearm.
 - Using a damaged bolt knob can cause injury or accidents.
- **Instructions for Avoiding Hazards:**
 - Ensure that the bolt knob is securely attached before using the rifle.
 - Do not attempt to modify or alter the bolt knob in any way.
 - Keep the bolt knob clean and free from debris to ensure smooth operation.
- **Age Specific Warnings:**
 - This product is intended for use by adults. Keep out of reach of children.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is unloaded.
- Remove the existing bolt knob by unscrewing it counterclockwise.
- Align the new bolt knob with the bolt and screw it in clockwise until secure.
- Check that the knob is firmly attached and does not wobble.

2. Usage:

- Use the bolt knob to operate the bolt mechanism of your hunting rifle.
- Apply even pressure when operating the bolt to ensure smooth function.
- Regularly check the tightness of the bolt knob during use to ensure it remains secure.

Disposal Instructions

- Dispose of the bolt knob in accordance with local regulations regarding plastic and metal waste.
- Do not dispose of the product in fire, as it may release harmful substances.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's website or contact their customer service.

By following these guidelines, you can ensure a safe and enjoyable experience with your STANDARD BOLT KNOB from Christensen Arms. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk