

REPLACEMENT CYLINDER POINTS - CRATEX POINT, EX-FINE, #6 CYL, 1/16" ARBOR

[Gunsmith Tools](#) > [Power Tools & Accessories](#) > [Rubber Abrasive Tools](#) > [Rubber Abrasive Cylinder Points](#)

Preshaped Abrasive Wheels For All Polishing/Grinding Needs

Bulk replacements sold 25 each per pkg. #6 Cylinder Point, $\frac{1}{4}$ " (6.3mm) diameter, $\frac{7}{8}$ " (22.2mm) long.



Attributes

- Name: [CRATEX POINT, EX-FINE, #6 CYL, 1/16" ARBOR](#)
- Manufacturer: [CRATEX](#)
- Product no.: 190025064
- Mfr. No.:
- Delivery weight: 0.041kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- Startpage
- Safety Instructions for REPLACEMENT CYLINDER POINTS CRATEX POINT, EXFINE, #6 CYL, 1/16" ARBOR
- About Us

Safety Instructions for REPLACEMENT CYLINDER POINTS CRATEX POINT, EXFINE, #6 CYL, 1/16" ARBOR

Introduction

Thank you for choosing the REPLACEMENT CYLINDER POINTS CRATEX POINT, EXFINE, #6 CYL, 1/16" ARBOR. This product is designed for precision use in various applications. It is important to follow safety guidelines to ensure safe handling and operation. This guide provides essential information to help you use the product safely and effectively.

General Safety Guidelines

- Always read and understand the safety instructions before using the product.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while using the product.
- Avoid prolonged inhalation of dust generated during use. Use a dust mask if necessary.
- Do not exceed the recommended operating speeds for the cylinder points.
- Ensure that the work area is wellventilated to minimize exposure to dust and debris.
- Do not use the product if it is damaged or worn out. Replace it immediately.

Instructions for Installation and Usage

1. Installation:

- Ensure that the power tool you are using is turned off and unplugged before installation.
- Carefully remove the existing cylinder point from the tool.
- Insert the new REPLACEMENT CYLINDER POINT into the tool's arbor securely.
- Tighten the arbor nut to ensure the cylinder point is firmly attached.
- Doublecheck that the cylinder point is properly installed before plugging in the tool.

2. Usage:

- Start the power tool at a low speed to allow the cylinder point to settle.
- Gradually increase the speed as needed for your application.
- Maintain a steady hand and control the tool to avoid slipping.
- Regularly pause to check the condition of the cylinder point during use.
- After completing your task, turn off and unplug the tool before removing the cylinder point.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check for any recycling programs that accept rubber abrasive products.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided on the product packaging or visit the manufacturer's website.

By following these safety instructions, you can ensure a safe and effective experience with the REPLACEMENT CYLINDER POINTS CRATEX POINT, EXFINE, #6 CYL, 1/16" ARBOR. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk