

BERETTA STAINLESS STEEL GUIDE ROD - CYLINDER & SLIDE S/S BERETTA GUIDE ROD

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Drop-In Replacement For Factory Plastic

No gunsmithing required to gain improved function and reliability with your Beretta Model 92 or 96. One-piece, stainless steel guide rod replaces the two-piece plastic Beretta factory guide rod; works with your factory recoil spring.



Attributes

- Name: [CYLINDER & SLIDE S/S BERETTA GUIDE ROD](#)
- Manufacturer: [CYLINDER & SLIDE](#)
- Product no.: 206000021
- Mfr. No.: CS0323
- Model: 92,96
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 000000003230

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- BERETTA STAINLESS STEEL GUIDE ROD SAFETY INSTRUCTIONS
- About Us

BERETTA STAINLESS STEEL GUIDE ROD SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the BERETTA STAINLESS STEEL GUIDE ROD. This product is designed to enhance the performance and reliability of your Beretta Model 92 or 96. It is essential to follow the safety instructions outlined in this guide to ensure safe and effective use.

General Safety Guidelines

- Ensure that the product is compatible with your Beretta Model 92 or 96 before use.
- Always handle firearms and related components with care and in accordance with standard safety practices.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the guide rod for any signs of wear or damage before each use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installation or maintenance.
- Use the guide rod only with the factory recoil spring designed for your Beretta model.
- Avoid using excessive force during installation to prevent damage to the guide rod or firearm.
- Do not modify the guide rod or use it in a manner not intended by the manufacturer.
- If you experience any malfunctions or irregularities during use, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Ensure your Beretta Model 92 or 96 is completely unloaded.
- Gather necessary tools, including a flat surface for installation.

2. Installation

- Remove the factory twopiece plastic guide rod by following the manufacturer's instructions.
- Take the new stainless steel guide rod and align it with the recoil spring.
- Gently insert the guide rod into the guide rod channel of the firearm.
- Ensure that the guide rod is seated properly and does not obstruct any moving parts.

3. Usage

- After installation, perform a function check to ensure proper operation.
- Regularly clean and maintain the guide rod to prevent corrosion and ensure longevity.
- Always follow safe handling practices when using your firearm.

Disposal Instructions

- Dispose of any damaged or nonfunctional parts in accordance with local regulations.
- Ensure that any components are disposed of in a manner that prevents access to children or unauthorized users.

Contact Information for Further Support

For any questions or concerns regarding the BERETTA STAINLESS STEEL GUIDE ROD, please refer to the manufacturer's customer service or support channels. Ensure you have the product information available for efficient assistance.

Thank you for your attention to these safety instructions. By following these guidelines, you can help ensure a safe and enjoyable experience with your BERETTA STAINLESS STEEL GUIDE ROD.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk