

FN-FAL ACCESSORY TOOLS - D.S. ARMS BUTTSTOCK WRENCH

[Gunsmith Tools](#) > [Rifle Tools](#) > [Gas System Tools](#)

Original FAL Tools For Service Repair

Authentic tools necessary to keep the FAL in top operating condition. Front Sight Tool easily adjusts the sight for correct elevation. Extractor Tool makes the difficult task of removing the extractor for cleaning or repair easy. Gas Wrench has the strength for removing the most stubborn regulator nut. Buttstock Wrench is necessary for control of recoil spring when removing the buttstock.



Attributes

- Name: [D.S. ARMS BUTTSTOCK WRENCH](#)
- Manufacturer: [D.S. ARMS](#)
- Product no.: 274100632
- Mfr. No.: 632FAL
- Model: FAL
- Weapon type: FN
- Delivery weight: 0.204kg
- Shipping height: 15mm
- Shipping width: 135mm
- Shipping length: 320mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [FNFAL Accessory Tools D.S. Arms Buttstock Wrench Safety Instructions](#)
- [About Us](#)

FNFAL Accessory Tools D.S. Arms Buttstock Wrench Safety Instructions

Introduction

Thank you for choosing the FNFAL Accessory Tools D.S. Arms Buttstock Wrench. This tool is essential for maintaining the FNFAL rifle in optimal operating condition. This safety instruction guide provides important information to ensure safe usage, proper installation, and disposal of the product. Please read this guide carefully before using the tool.

General Safety Guidelines

- Always handle tools with care to prevent injury.
- Keep tools out of reach of children and unauthorized users.
- Regularly inspect tools for wear or damage before use.
- Use the tools only for their intended purpose.
- Wear appropriate personal protective equipment (PPE), such as gloves and safety glasses, during use.
- Follow all local laws and regulations regarding firearm maintenance and safety.

Specific Safety Precautions for Use

- **Front Sight Tool:**
 - Ensure the rifle is unloaded before adjusting the front sight.
 - Adjust sights gradually to avoid overadjusting, which may affect accuracy.
- **Extractor Tool:**
 - Use the extractor tool only when the rifle is completely disassembled.
 - Avoid excessive force when removing the extractor to prevent damage.
- **Gas Wrench:**
 - Ensure the gas system is cool before use to prevent burns.
 - Use the gas wrench to apply even pressure to avoid stripping the regulator nut.
- **Buttstock Wrench:**
 - Always ensure the recoil spring is under control when removing the buttstock.
 - Keep hands clear of the recoil spring mechanism to prevent injury.

Instructions for Installation and Usage

1. Using the Front Sight Tool:

- Ensure the rifle is unloaded.
- Align the tool with the front sight post.
- Turn the tool to adjust the elevation as needed.

2. Using the Extractor Tool:

- Disassemble the rifle completely.
- Insert the extractor tool into the extractor slot.

- Gently twist and pull to remove the extractor.

3. Using the Gas Wrench:

- Allow the gas system to cool.
- Position the gas wrench over the regulator nut.
- Turn counterclockwise to loosen and remove the nut.

4. Using the Buttstock Wrench:

- Ensure the recoil spring is properly controlled.
- Position the buttstock wrench on the buttstock screw.
- Turn counterclockwise to remove the buttstock.

Disposal Instructions

- Dispose of the tool responsibly and in accordance with local regulations.
- If the tool is damaged beyond repair, consider recycling if possible.
- Do not dispose of tools in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the FNFAL Accessory Tools D.S. Arms Buttstock Wrench, please refer to the contact information provided by the manufacturer or your local retailer. Ensure you have the product details available for reference.

Thank you for prioritizing safety and proper maintenance of your FNFAL rifle.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk