

1911 TITANIUM MAINSPRING CAP - EGW TI MAINSPRING CAP, GOVT/COMM.

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Caps](#)

Light Weight Helps Decrease Lock Time

Use as an integral part of a lightweight ignition system to reduce overall lock time and increase accuracy. Machined from solid titanium for strength and long service life.



Attributes

- Name: [EGW TI MAINSPRING CAP, GOVT/COMM.](#)
- Manufacturer: [EGW](#)
- Product no.: 296000086
- Mfr. No.: 10180
- Finish: Stainless Steel
- Model: Commander, Government
- Weapon type: 1911
- Delivery weight: 0.005kg
- Shipping height: 8mm
- Shipping width: 76mm
- Shipping length: 118mm
- UPC: 841370100484

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Titanium Mainspring Cap
- About Us

Safety Instruction Guide for 1911 Titanium Mainspring Cap

Introduction

Thank you for choosing the 1911 Titanium Mainspring Cap by EGW. This product is designed to enhance the performance of your lightweight ignition system, ensuring reduced lock time and increased accuracy. It is essential to follow the safety instructions provided in this guide to ensure safe usage and optimal performance.

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Ensure that the product is compatible with your firearm model (1911 Government and Commander).
- Inspect the product for any damage before installation. Do not use if damaged.
- Keep the product out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding firearm modifications and accessories.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Handle the mainspring cap with care to avoid injury.
- Avoid using excessive force during installation to prevent damage to the cap or firearm.
- Ensure that the firearm is unloaded before installing or replacing the mainspring cap.
- Do not modify the mainspring cap in any way, as this may compromise its safety and performance.
- Regularly check the mainspring cap for wear and replace it if necessary.

Instructions for Installation and Usage

1. Preparation

- Ensure that your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, if required.

2. Installation Steps

- Remove the existing mainspring cap from your firearm.
- Inspect the area for any debris or damage.
- Take the new titanium mainspring cap and align it with the mainspring housing.
- Gently press the cap into place, ensuring it fits securely without excessive force.
- Confirm that the cap is properly seated and that there are no gaps.

3. PostInstallation Checks

- After installation, perform a function check of your firearm to ensure everything operates correctly.
- Store your firearm in a safe location when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations for metal recycling.
- Do not dispose of the product in household waste. Check with your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries or support regarding the product, please consult the manufacturer's website or contact your local dealer.

By following these safety instructions, you can ensure a safe and effective experience with your 1911 Titanium Mainspring Cap. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk