

PUSH BUTTON QD SLING SWIVEL - BLUE FORCE GEAR PUSH BUTTON QD SLING SWIVEL 1"

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Tactical Sling Mounts](#)

The Push Button QD Sling Swivel provides a secure, quiet sling attachment point and allows slings to be quickly removed and installed on multiple weapons. The Push Button Sling Swivel can be threaded on to any Vickers Slings. The Blue Force Gear Push Button Sling Swivel was designed to be stronger and lighter than the common Push Button QD Swivels. The smaller swivel body and push button reduces weight while minimizing the chance of accidentally disengaging the swivel. A larger gauge sling loop gives increased strength and durability. The Push Button Quick Detach Sling Swivel has a matte phosphate finish for corrosion resistance and signature reduction. The Push Button Sling Swivels fit all common quick detach (QD Swivel) sockets found on some buttstocks, forends, rails, or aftermarket socket adapters. Ensure that your weapon has a QD socket to correctly attach the sling to the weapon. For attaching a Push Button Sling Swivel to railed forends without integral QD sockets, you can use the Rail Mounted Push Button Swivel Socket. For a true quick release sling swivel, see the RED Swivel - a push button swivel that is installed and removed by pulling on the emergency release knob. Contrary to push belief, the common QD swivel is not an emergency release point as the ""push then pull"" motion is fine motor skill and can be difficult with gloves or in stressful situations. *** Place a small drop of oil or gun lube down the push button channel every time you clean your weapon to ensure smooth operation and protect the internals from corrosion *** Choosing between 1" and 1.25" loops: 1" Swivels can be used on any Vickers Sling that has 1.25" webbing. The 1" loop keeps the Swivel more stationary on the sling. 1.25" Swivels can also be used on any Vickers Sling but allows for more movement of the webbing than the 1" Swivels



Attributes

- Name: [BLUE FORCE GEAR PUSH BUTTON QD SLING SWIVEL 1"](#)
- Manufacturer: [BLUE FORCE GEAR](#)
- Product no.: 430100709
- Mfr. No.: PB-100
- Colour: Black
- Delivery weight: 0.025kg
- Shipping height: 6mm
- Shipping width: 32mm
- Shipping length: 25mm
- UPC: 814520014092

Item details

Made in USA

Table of Contents

- Startpage
- PUSH BUTTON QD SLING SWIVEL SAFETY INSTRUCTIONS
- About Us

PUSH BUTTON QD SLING SWIVEL SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Push Button QD Sling Swivel by Blue Force Gear. This safety instruction guide is designed to help you use the product safely and effectively. Please read this guide carefully before use to ensure a safe experience.

General Safety Guidelines

- Ensure that your weapon is equipped with a Quick Detach (QD) socket before attaching the sling swivel.
- Always inspect the sling swivel before each use for any signs of wear or damage.
- Do not exceed the recommended weight limit for the sling swivel to avoid failure.
- Keep the sling swivel and its components clean and lubricated to ensure proper function.
- Store the sling swivel in a dry place to prevent corrosion.

Specific Safety Precautions for Use

- Always verify that the sling swivel is securely attached to the weapon before use.
- Avoid using the sling swivel with incompatible slings or attachments.
- Do not force the push button if it is stuck; instead, check for obstructions or lubrication issues.
- Use caution when handling the sling swivel in adverse conditions, such as extreme temperatures or wet environments.
- Do not use the sling swivel to carry or support any loads other than those intended for firearm use.

Instructions for Installation and Usage

1. Attaching the Sling Swivel:

- Ensure your weapon has a compatible QD socket.
- Align the push button on the sling swivel with the QD socket.
- Press the push button and insert the swivel into the socket until it clicks into place.
- Release the push button to secure the swivel. Ensure it is firmly attached.

2. Using the Sling Swivel:

- Adjust the sling length to your preference before use.
- Always check the attachment before moving or firing the weapon.
- For railed forends without integral QD sockets, use the Rail Mounted Push Button Swivel Socket for attachment.

3. Maintenance:

- Clean the sling swivel regularly to remove dirt and debris.
- Apply a small drop of oil or gun lube to the push button channel after cleaning to ensure smooth operation.
- Inspect the swivel for any corrosion or damage before each use.

Disposal Instructions

- Dispose of the sling swivel in accordance with local regulations.
- If the sling swivel is damaged beyond repair, ensure it is disposed of in a way that prevents accidental

use.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of the Push Button QD Sling Swivel, please refer to the product packaging or your retailer for contact information.

Thank you for your attention to these safety instructions. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk