

DAKA® WATERPROOF WINDOW POUCHES - MAGPUL DAKA WATERPROOF WINDOW POUCH LARGE ORANGE

[Emergency & Survival Gear](#) > [Backpacks & Bags](#) > [Pouches](#)

The DAKA Waterproof Window Pouch takes Magpul's extremely popular DAKA Pouches and closes the loop on making them usable in situations where being absolutely waterproof is a must. The YKK® zippers have been placed laterally on the side of the DAKA Waterproof Pouches, providing complete, reliable water resistance you can depend on when being submerged is a real possibility. The durable zipper pulls are made of 550 paracord and heat shrink tubing, and they're easy to grasp when wet or when you have gloves on. Other features include a fully translucent window panel for easy contents ID, two extra-large carabiner pass-throughs for attaching to just about anything. The DAKA Waterproof Window Pouch is a necessary piece of gear when keeping your valuables waterproof is a must. FEATURES Rugged, 100% waterproof YKK zipper that's easy-to-open and close 550 paracord zipper pull Strong RF welded construction that creates permanent, impenetrable seals Magpul's unique polymer-infused material protects your stuff from exposure Translucent window on one side Large carabiner attachment points

SMALL POUCH SPECS Overall dimensions: 6 x 9 in. External height: 6.0 in. Internal height: 5.75 in. External width: 9.0 in. Internal width: 8.75 in. Internal volume: 0.45L

MEDIUM POUCH SPECS Overall dimensions: 7 x 12 in. External height: 7.0 in. Internal height: 6.75 in. External width: 12.0 in. Internal width: 11.75 in. Internal volume: 1.45L

LARGE POUCH SPECS Overall dimensions: 9 x 13 in. External height: 9.0 in. Internal height: 8.75 in. External width: 13.0 in. Internal width: 12.75 in. Internal volume: 3.18L



Attributes

- Name: [MAGPUL DAKA WATERPROOF WINDOW POUCH LARGE ORANGE](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 430106529
- Mfr. No.: MAG1339-811
- Colour: Orange
- Delivery weight: 0.454kg
- Shipping height: 13mm
- Shipping width: 381mm
- Shipping length: 229mm
- UPC: 840815142911

Table of Contents

- [Startpage](#)
- [DAKA® Waterproof Window Pouches Safety Instructions](#)
- [About Us](#)

DAKA® Waterproof Window Pouches Safety Instructions

Introduction

Thank you for choosing the DAKA Waterproof Window Pouches by Magpul. These pouches are designed to keep your valuables safe and dry in various conditions. This guide provides essential safety instructions and guidelines to ensure the safe use of this product.

General Safety Guidelines

- Always ensure the pouch is properly sealed before exposure to water.
- Regularly inspect the pouch for any signs of wear or damage to ensure continued waterproof performance.
- Keep the pouch away from sharp objects that may puncture or tear the material.
- Store the pouch in a cool, dry place when not in use to prolong its lifespan.
- Do not expose the pouch to extreme temperatures for extended periods.
- Be aware that while the pouch is waterproof, it is not intended for prolonged submersion in water.

Specific Safety Precautions for Use

- Ensure that the contents of the pouch are suitable for waterproof storage.
- Avoid overloading the pouch beyond its specified internal volume.
- When using the zipper, pull it gently to avoid damaging the mechanism.
- If using the pouch while engaging in water activities, ensure it is securely attached to your person or equipment to prevent loss.
- Do not use the pouch as a flotation device; it is not designed for this purpose.
- Keep the pouch out of reach of children to prevent accidental use or suffocation hazards.

Instructions for Installation and Usage

1. Preparing the Pouch:

- Open the pouch by gently pulling the zipper.
- Ensure that the zipper is free of debris or obstructions before use.

2. Loading the Pouch:

- Place your items inside the pouch, ensuring they fit comfortably without forcing them.
- Do not exceed the internal volume specified for your pouch size.

3. Sealing the Pouch:

- Close the zipper completely, ensuring it is aligned correctly.
- Pull the zipper gently but firmly to ensure a watertight seal.
- Doublecheck that there are no gaps or openings in the seal.

4. Attaching the Pouch:

- Use the large carabiner attachment points to secure the pouch to your backpack, belt, or other gear.
- Ensure that the attachment is secure and will not come loose during use.

5. Using the Pouch:

- Carry the pouch in a manner that minimizes exposure to potential hazards.
- If the pouch becomes wet, dry it thoroughly before storing.

Disposal Instructions

- Dispose of the pouch in accordance with local regulations for plastic and synthetic materials.
- Do not incinerate the pouch, as it may release harmful chemicals.
- If the pouch is damaged or no longer usable, consider recycling options if available.

Contact Information for Further Support

For any inquiries regarding the safety and use of the DAKA Waterproof Window Pouches, please contact the manufacturer or refer to the product packaging for additional support information.

Conclusion

By following these safety instructions, you can ensure the effective use of your DAKA Waterproof Window Pouch while keeping your belongings safe and secure. Thank you for your attention to safety, and enjoy your outdoor adventures with confidence.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk