

URG-I AIRBORNE 5.56 CHARGING HANDLE - GEISSELE AUTOMATICS

URG-I AIRBORNE 5.56 CHARGING HANDLE BLACK

[Rifle Parts](#) > [Bolt Parts](#) > [Charging Handle Parts](#) > [Charging Handles](#)

URG-I Airborne Charging Handle 5.56 The Airborne Charging Handle (ACH), was originally developed at the request of an elite organization famous for its expertise in aerial insertion. Now adopted by USASOC and field tested in the most arduous environments, The USASOC ACH now features a roll marked "Geissele Automatics" and the ACH's NSN number diminishing the amount of laser engraving and reducing its visual signature. Unchanged are the lower profile lever design that reduces chances of snagging on gear. The handling surfaces of the levers are checkered for confident operation while wearing gloves or during engagements in less than optimal weather conditions. The Geissele USASOC ACH features a gas mitigating fence at the rear that aids in redirecting gas blow back when shooting short barreled and suppressed weapon systems. The ambidextrous USASOC ACH is 3D machined from a solid block of aircraft grade 7075-T6 aluminum and finished in durable Type-3 Hardcoat anodized. The USASOC ACH weighs in at 1.42oz. URG-I Airborne Charging Handle 5.56 Specification The USASOC Airborne Charging Handle (NSN# 1005-01-672-4803) has been adopted and is currently fielded by USASOC. This version uses rollmarks instead of laser engraving to diminish its visual signature. The USASOC ACH is available in DDC and Black.



Attributes

- Name: [GEISSELE AUTOMATICS URG-I AIRBORNE 5.56 CHARGING HANDLE BLACK](#)
- Manufacturer: [GEISSELE AUTOMATICS](#)
- Product no.: 430107548
- Mfr. No.: 05-664B
- Finish: Black
- Hand: Ambidextrous
- Style: -
- Weapon type: AR-15
- Delivery weight: 0.023kg
- Shipping height: 6mm
- Shipping width: 127mm
- Shipping length: 197mm
- UPC: 817953027165

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- URGI Airborne 5.56 Charging Handle Safety Instructions
- About Us

URGI Airborne 5.56 Charging Handle Safety Instructions

Introduction

Thank you for choosing the URGI Airborne 5.56 Charging Handle by Geissele Automatics. This guide provides essential safety instructions, installation guidelines, and usage recommendations to ensure your safety and the proper functioning of the product. Please read this manual thoroughly before use.

General Safety Guidelines

- Ensure that the charging handle is compatible with your firearm model before installation.
- Always handle firearms with care and treat every weapon as if it is loaded.
- Keep the charging handle and all firearm components out of reach of children and unauthorized users.
- Regularly inspect the charging handle for any signs of wear or damage. Replace if necessary.
- Do not attempt to modify or alter the charging handle in any way.
- Always wear appropriate protective gear, including eye protection, when handling firearms.

Specific Safety Precautions for Use

- The charging handle is designed for use with shortbarreled and suppressed weapon systems. Ensure proper alignment and installation to avoid malfunctions.
- When using the charging handle, maintain a firm grip to prevent slipping during operation.
- Avoid using the charging handle in adverse weather conditions unless necessary. If used in rain or snow, ensure that it is dry before handling.
- Be aware of your surroundings and ensure that no one is in the line of fire when operating the charging handle.
- If you experience any malfunctions or irregularities while using the charging handle, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing charging handle from the firearm by following the manufacturer's instructions.
- Align the URGI Airborne Charging Handle with the receiver and insert it into the designated slot.
- Ensure that the charging handle is securely in place and operates smoothly.
- Perform a function check to ensure proper operation before using the firearm.

2. Usage:

- To charge the firearm, grasp the charging handle firmly with your dominant hand.
- Pull the charging handle back fully to the rear position and release it to chamber a round.
- Ensure that the firearm is aimed in a safe direction before charging.
- After charging, keep your finger off the trigger until you are ready to fire.

Disposal Instructions

- Dispose of the URGI Airborne Charging Handle responsibly.
- Follow local regulations for the disposal of metal components.
- Do not dispose of the charging handle in regular household waste.

Contact Information for Further Support

For safety inquiries or support, please reach out to the appropriate contact point as per local regulations.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on your adherence to these guidelines. Always prioritize safety when handling firearms and their components.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk