

DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DECAPPING PIN - LEE PRECISION DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DEPPING PIN

[Reloading](#) > [Case Cleaning](#) > [Decapping Dies & Accessories](#)

Double ended undersized flash hole universal decapping pin for our Universal Decapping Die (#90292) or Undersize Flash Hole Universal Decapping Die (# 91976). Pin diameter .055"



Attributes

- Name: [LEE PRECISION DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DEPPING PIN](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 430108746
- Mfr. No.: 91916
- Delivery weight: 0.017kg
- Shipping height: 5mm
- Shipping width: 102mm
- Shipping length: 114mm
- UPC: 734307919160

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DECAPPING PIN
- About Us

Safety Instruction Guide for DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DECAPPING PIN

Introduction

Thank you for choosing the DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DECAPPING PIN from LEE PRECISION. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this document carefully before using the decapping pin.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Always keep the decapping pin out of reach of children and vulnerable individuals.
- Inspect the decapping pin before each use to ensure it is in good condition.
- Avoid using the decapping pin if it shows signs of damage or wear.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use the decapping pin only with compatible dies: Universal Decapping Die (#90292) or Undersize Flash Hole Universal Decapping Die (#91976).
- Handle the decapping pin with care to avoid injury.
- Do not apply excessive force when using the decapping pin, as this may lead to breakage or injury.
- Always wear appropriate personal protective equipment, such as safety glasses, when using the decapping pin.
- Avoid using the decapping pin in wet or damp conditions to prevent slipping.

Instructions for Installation and Usage

1. Installation:

- Ensure the decapping die is securely mounted in your reloading press.
- Insert the double ended undersized flash hole universal decapping pin into the die according to the manufacturer's instructions.
- Tighten the set screw to secure the pin in place.

2. Usage:

- Prepare your brass casing by ensuring it is clean and free of debris.
- Place the brass casing in the die and apply even pressure to the handle of your reloading press.
- The decapping pin will remove the primer from the casing. If the primer does not come out easily, stop and inspect for any issues.
- After decapping, remove the brass casing and inspect for any damage.

Disposal Instructions

- Dispose of the decapping pin responsibly. If the pin is damaged or no longer usable, follow local regulations for disposal of metal products.
- Ensure that any used primers and casings are disposed of according to local hazardous waste guidelines.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact point provided with the product packaging.

Thank you for using the DOUBLE ENDED UNDERSIZED FLASH HOLE UNIVERSAL DECAPPING PIN. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk