

RIFLE FACTORY CRIMP DIES - LEE PRECISION .360 BUCKHAMMER FACTORY CRIMP DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Lee Factory Crimp Die crimps the bullet in place more firmly than any other tool. Tests demonstrate that even bullets which have no crimp groove will shoot more accurately. A firm crimp improves accuracy because pressure must build to a higher level before the bullet begins to move. This higher start pressure insures a more uniform pressure curve and less velocity variation. Features a collet that squeezes the case mouth into the crimping groove for a firm hold. Shellholder not included. Fits all 7/8"-14 reloading presses.



Attributes

- Name: [LEE PRECISION .360 BUCKHAMMER FACTORY CRIMP DIE](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 430109252
- Mfr. No.: 92035
- Cartridge: 360 Buckhammer
- Die Style: Factory Crimp Die
- Delivery weight: 0.136kg
- Shipping height: 38mm
- Shipping width: 38mm
- Shipping length: 121mm
- UPC: 734307920357

Item details

Made in USA

Table of Contents

- Startpage
- RIFLE FACTORY CRIMP DIES LEE PRECISION .360 BUCKHAMMER FACTORY CRIMP DIE Safety Instruction Guide
- About Us

RIFLE FACTORY CRIMP DIES LEE PRECISION .360 BUCKHAMMER FACTORY CRIMP DIE Safety Instruction Guide

Introduction

Thank you for choosing the RIFLE FACTORY CRIMP DIES by LEE PRECISION. This guide provides essential safety instructions to ensure the safe and effective use of your Factory Crimp Die. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Always handle the die with care to prevent injury.
- Ensure that you are using the die in accordance with the manufacturer's instructions.
- Store the die in a secure and dry location, out of reach of children.
- Regularly inspect the die for signs of wear or damage before each use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using the die.
- Ensure that the reloading press is securely mounted and stable before operation.
- Do not exceed the recommended load specifications for your ammunition.
- Avoid distractions while operating the reloading press to maintain focus.
- Never point the die or any loaded ammunition towards yourself or others.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is turned off and unplugged.
- Remove any existing dies from the press.
- Screw the Factory Crimp Die into the press using the 7/8"14 thread.
- Tighten the die securely but do not overtighten.

2. Usage

- Insert the cartridge case into the shell holder of the press.
- Raise the ram to position the case in the die.
- Adjust the die to achieve the desired crimp by turning the die body.
- Lower the ram to apply the crimp to the bullet seated in the case.
- Inspect the crimped bullet for uniformity and consistency.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of ammunition or reloading components in regular household waste.
- Contact local hazardous waste disposal facilities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided with your product.

Conclusion

By following this safety instruction guide, you can ensure the safe and effective use of the RIFLE FACTORY CRIMP DIES LEE PRECISION .360 BUCKHAMMER FACTORY CRIMP DIE. Always prioritize safety and adhere to all guidelines for a successful reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk