

BRN-22 FIRING PIN SPRING - BROWNELLS BRN-22 FIRING PIN

[Rifle Parts](#) > [Bolt Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

Replacement BRN-22 Firing Pin. Firing Pin is backwards compatible with standard Ruger® 10/22® bolts. Firing Pin is machined from 17-4 PH Stainless Steel, then ground and polished for smooth operation.



Attributes

- Name: [BROWNELLS BRN-22 FIRING PIN](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 430109574
- Mfr. No.: AZTP-22-SS-002
- Model: BRN-22
- Weapon type: Brownells
- Delivery weight: 0.136kg
- Shipping height: 3mm
- Shipping width: 3mm
- Shipping length: 89mm
- UPC: 050806001190

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- BRN22 Firing Pin Safety Instructions
- About Us

BRN22 Firing Pin Safety Instructions

Introduction

Thank you for purchasing the BRN22 Firing Pin. This guide provides important safety information and instructions to ensure safe use and proper installation of the product. Please read this manual carefully before use.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as a replacement firing pin for Ruger® 10/22® bolts.
- Always handle the firing pin with care to prevent personal injury.
- Keep the firing pin and all related components out of reach of children and unauthorized users.
- Regularly inspect the firing pin for signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding firearms and their components.

Specific Safety Precautions for Use

- Use appropriate protective gear, such as safety glasses, when handling or installing the firing pin.
- Ensure that the firearm is unloaded and pointed in a safe direction before proceeding with installation.
- Do not attempt to modify or alter the firing pin in any way.
- If you experience any issues during installation or use, cease operation immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, including a small screwdriver or punch tool.

2. Installation:

- Remove the bolt from the Ruger® 10/22® firearm according to the manufacturer's instructions.
- Locate the firing pin assembly within the bolt.
- Carefully remove the old firing pin, ensuring no parts are lost.
- Install the BRN22 Firing Pin by aligning it with the firing pin channel and gently pressing it into place.
- Ensure that the firing pin is seated correctly and moves freely within the channel.

3. Testing:

- After installation, reassemble the bolt and insert it back into the firearm.
- Conduct a function check with the firearm in a safe environment to ensure proper operation.
- If any issues arise, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of any old or damaged firing pins in accordance with local regulations for hazardous waste.
- Do not throw away in regular household waste. Contact local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product concerns, please refer to the manufacturer's website or contact their customer support service. Ensure you have your product details handy for assistance.

Conclusion

Following these safety instructions will help ensure the safe and effective use of the BRN22 Firing Pin. Always prioritize safety and compliance with applicable laws when handling firearms and their components. Thank you for choosing our product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk