

# INFINITY APS DIE INSERTS - SHORT ACTION CUSTOMS, LLC.

## INFINITY AAPS DIE INSERT TYPE 6

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

The INFINITY APS Die (Arbor Press Series) is designed to be the ONLY bullet seating die you will ever need when reloading cartridges from 223 Remington to the 338 Lapua Magnum from an Arbor style press. The Infinity Bullet APS Seating Die comes complete with 6 different bullet seating stems and 2 cartridge centering sleeves to handle conventional and solid turned bullets from 20 to 338 caliber, simply select the appropriate Cartridge Base Insert and you're ready to create high quality ammunition. Base Inserts fit the following Cartridge Families: Type 1 - 223 Remington Based Cartridges Type 2 - Valkyrie Based Cartridges Type 3 - PPC, Grendel, SPC Based Cartridges Type 4 - Short Action 308 Winchester & Creedmoor Based Cartridges Type 4 XL - Long Action 308 Win & 30-06 Based Cartridges Type 5 - 284 Winchester Based Cartridges Type 6 - Short Action PRC Based Cartridges Type 6 XL - Long Action PRC, Belted & Weatherby Magnum Based Cartridges Type 7 - SAUM Based Cartridges Type 7 XL - Nosler and RUM Based Cartridges Type 8 - WSM Based Cartridges Type 9 - Lapua and Norma Magnum based Cartridges



### Attributes

- Name: [SHORT ACTION CUSTOMS, LLC. INFINITY AAPS DIE INSERT TYPE 6](#)
- Manufacturer: [SHORT ACTION CUSTOMS, LLC.](#)
- Product no.: 430109985
- Mfr. No.: SAC-IAPDCB6
- Cartridge: 6.5 PRC, 7mm PRC
- Die Style: Seater Die
- Delivery weight: 0.181kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 102mm

### Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for INFINITY APS DIE INSERTS
- About Us

# Safety Instruction Guide for INFINITY APS DIE INSERTS

## Introduction

Thank you for choosing the INFINITY APS Die from SHORT ACTION CUSTOMS, LLC. This bullet seating die is designed to provide you with a reliable and efficient solution for reloading cartridges. Please read this safety instruction guide carefully to ensure safe and effective use of the product. It is essential to follow all guidelines and precautions outlined in this document to prevent accidents and ensure optimal performance.

## General Safety Guidelines

- Ensure that the INFINITY APS Die is used only for its intended purpose: reloading cartridges from 223 Remington to 338 Lapua Magnum.
- Always wear appropriate safety gear, including safety glasses and hearing protection, when using reloading equipment.
- Keep the work area clean and free of distractions to maintain focus while reloading.
- Store the die and all reloading components in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the die for wear or damage. Do not use if any parts are damaged or missing.
- Follow all manufacturer instructions and safety warnings included with the product.

## Specific Safety Precautions for Use

- Before using the INFINITY APS Die, ensure that your Arbor style press is compatible and securely mounted.
- Always doublecheck that the correct Cartridge Base Insert is selected for the cartridge you are reloading.
- Do not exceed recommended load limits when reloading cartridges, as this could lead to dangerous malfunctions.
- Avoid using damaged or wornout components, as they may compromise safety and performance.
- Never leave the reloading process unattended. Stay focused and aware of your surroundings.
- Ensure that all components, including bullets and powder, are stored safely and in accordance with local regulations.

## Instructions for Installation and Usage

### 1. Preparation:

- Gather all necessary materials, including the INFINITY APS Die, Cartridge Base Inserts, bullet seating stems, and cartridges to be reloaded.
- Ensure that your workspace is clean and organized.

### 2. Installation:

- Secure the Arbor style press to a stable work surface.
- Insert the INFINITY APS Die into the Arbor press according to the manufacturer's instructions.
- Select the appropriate Cartridge Base Insert based on the cartridge family you will be working with.
- Attach the selected bullet seating stem to the die.

### 3. Using the Die:

- Place the cartridge case in the die and ensure it is properly centered.
- Adjust the seating depth according to your specifications.

- Slowly and steadily operate the Arbor press to seat the bullet into the cartridge case.
- Inspect the completed cartridge for proper bullet seating and any visible defects.

#### **4. PostUse:**

- After reloading, clean the die and all components to remove any residue.
- Store the INFINITY APS Die and related components in a secure location.

## **Disposal Instructions**

- Dispose of any defective or damaged components in accordance with local regulations.
- Recycle packaging materials where possible to minimize environmental impact.
- Do not dispose of any hazardous materials, such as powder or primers, in regular trash. Follow local guidelines for hazardous waste disposal.

## **Contact Information for Further Support**

For additional support or inquiries regarding safety and usage of the INFINITY APS Die, please refer to the manufacturer's contact information provided with your product. It is important to reach out for assistance if you have any questions or concerns about the safe operation of this reloading equipment.

By adhering to these safety guidelines and instructions, you can ensure a safe and effective reloading experience with the INFINITY APS Die. Thank you for your commitment to safety and quality in your reloading practices.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)