

1911 EXTENDED SLIDE STOP - JOHN MASEN EXTENDED GRAY SLIDE STOP, CK

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

Extra Length For Faster Slide Engagement

Moves the contact pad rearward and out for faster, easierslide engagement.
Makes the slide stop more accessible for shooters with smaller hands.

Available with serrated (SR) or 20 lpi checkered (CK) thumb pad. Hardened and heat treated pin.



Attributes

- Name: [JOHN MASEN EXTENDED GRAY SLIDE STOP, CK](#)
- Manufacturer: [JOHN MASEN](#)
- Product no.: 555105211
- Mfr. No.:
- Caliber: 45 Caliber (.451-.454)
- Finish: Matte Gray
- Make: 1911
- Model: Officers, Government, Commander
- Delivery weight: 0.045kg

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Extended Slide Stop
- About Us

Safety Instruction Guide for 1911 Extended Slide Stop

Introduction

Thank you for choosing the 1911 Extended Slide Stop by John Masen. This product is designed to enhance the functionality of your firearm while ensuring safe and effective use. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure that you are in a secure environment when handling your firearm.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the slide stop for wear or damage before use.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or adjusting the slide stop.
- Only use the slide stop with compatible models: Government, Commander, and Officers.
- Check that the thumb pad is securely attached before using the firearm.
- Avoid using excessive force when engaging or disengaging the slide stop.
- Do not modify the slide stop or use it in a manner not intended by the manufacturer.
- If you experience any issues with the slide stop, discontinue use and seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is completely unloaded.
- Remove the existing slide stop by pushing the pin out.
- Insert the new John Masen Extended Slide Stop into the slide.
- Secure the slide stop with the hardened and heat-treated pin provided.
- Verify that the slide stop is properly seated and functions correctly.

2. Usage:

- To engage the slide stop, pull the slide back fully and release it.
- To disengage the slide stop, press the thumb pad with your thumb.
- Practice using the slide stop in a controlled environment to become familiar with its operation.

Disposal Instructions

- When disposing of the product, follow local regulations for the disposal of firearm accessories.
- Do not dispose of the slide stop in regular household waste.
- If the product is damaged or no longer in use, consider recycling metal components where possible.

Contact Information for Further Support

For any questions or concerns regarding the 1911 Extended Slide Stop, please reach out to the designated EU contact point for safety inquiries. Ensure you have your product information ready for a more efficient response.

By following these guidelines, you can ensure safe and effective use of your 1911 Extended Slide Stop. Thank you for prioritizing safety in your firearm handling practices.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu