

UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL - UNCLE MIKES 1011-2 W/1" LOOPS SEE SPECS #10 FOR MODELS

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Flush Mount Sling Swivels](#)

Universal Design Fits Virtually Every Bolt Action Rifle Made

Quickly attaches or detaches with recessed push button. Provides secure sling attachment that can't come loose. Mounting system will fit nearly every centerfire or rimfire bolt action made, plus many other action types. When detached, leaves a non-snag, flush base. Use Epoxy to hold base in stock, no screw required.



Attributes

- Name: [UNCLE MIKES 1011-2 W/1" LOOPS SEE SPECS #10 FOR MODELS](#)
- Manufacturer: [UNCLE MIKES](#)
- Product no.: 593101100
- Mfr. No.: MO10112
- Material: Steel
- Style: Flush Mount Swivel
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 74mm
- Shipping length: 130mm
- UPC: 043699101122

Table of Contents

- Startpage
- UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL SAFETY INSTRUCTION GUIDE
- About Us

UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL SAFETY INSTRUCTION GUIDE

Introduction

Thank you for purchasing the UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL. This guide provides essential safety instructions and information to ensure the safe use and installation of your sling swivel. Please read this document thoroughly before use.

General Safety Guidelines

- Always ensure that the sling swivel is compatible with your firearm before installation.
- Inspect the sling swivel for any signs of damage or wear before each use.
- Do not exceed the recommended weight limit for the sling swivel.
- Keep the sling swivel out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Avoid Misuse:** Do not use the sling swivel for purposes other than its intended use.
- **Check Attachment:** Ensure the sling swivel is securely attached to the firearm before use.
- **Regular Inspections:** Periodically check the swivel and mounting system for signs of wear or loosening.
- **Proper Handling:** Always handle firearms with care and follow the manufacturer's safety guidelines.

Instructions for Installation and Usage

Installation

1. **Prepare the Area:** Work in a clean, dry area free from distractions.
2. **Gather Tools:** You will need epoxy to secure the base in the stock. No screws are required.
3. **Attach the Base:**
 - Apply epoxy to the base of the sling swivel.
 - Position the base in the desired location on the forend wood.
 - Hold in place until the epoxy sets as per the manufacturer's instructions.
4. **Check the Fit:** Ensure that the base is flush and nonsnagging.

Usage

1. **Attaching the Sling:**
 - Press the recessed push button to attach the sling to the swivel.
 - Ensure the sling is securely fastened.
2. **Detaching the Sling:**
 - Press the recessed push button to detach the sling.
 - Store the sling safely when not in use.
3. **Weight Limit:** Ensure that the total weight of the attached sling and any equipment does not exceed the recommended limits.

Disposal Instructions

- Dispose of any packaging materials responsibly according to local regulations.
- When the sling swivel reaches the end of its life, dispose of it in accordance with local waste disposal regulations.

- Do not dispose of the product in household waste; check for designated recycling points.

Contact Information for Further Support

For questions or concerns regarding the safety and use of the UNCLE MIKE'S QUICK DETACH 100 SLING SWIVEL, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for choosing UNCLE MIKE'S products. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk