

MEC MAINTENANCE KIT - MAINTENANCE KIT

[Reloading](#) > [Reloading Presses](#) > [Shotshell Presses](#)

MEC Maintenance Kit has all of the tools you need to keep your MEC reloader operating efficiently. Kit contains: Anti-Seize Lubricant, Pick, Brush, Column Spring Lifter and Closure Nut Wrench.



Attributes

- Name: [MAINTENANCE KIT](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749010898
- Mfr. No.: 8948
- Cartridge: 45-60 Winchester
- Delivery weight: 0.227kg
- Shipping height: 15mm
- Shipping width: 76mm
- Shipping length: 272mm
- UPC: 098489028608

Item details

Made in USA

Table of Contents

- Startpage
- MEC Maintenance Kit Safety Instructions
- About Us

MEC Maintenance Kit Safety Instructions

Introduction

Thank you for choosing the MEC Maintenance Kit. This kit is designed to help you maintain your MEC reloader effectively and safely. Please read this safety instruction guide carefully to ensure safe and proper use of the kit.

General Safety Guidelines

- Ensure that the workspace is clean and free from clutter before using the MEC Maintenance Kit.
- Always wear appropriate personal protective equipment (PPE), such as safety goggles and gloves, when handling tools and lubricants.
- Keep the kit out of reach of children and pets to prevent accidental use or injury.
- Do not use the kit for any purpose other than its intended use as specified in this guide.
- Regularly inspect all tools and components for wear or damage before use. Replace any damaged items immediately.

Specific Safety Precautions for Use

- **AntiSeize Lubricant:**
 - Avoid skin contact. If contact occurs, wash thoroughly with soap and water.
 - Use in a wellventilated area to avoid inhalation of fumes.
- **Pick:**
 - Use caution when handling the pick to avoid puncture wounds. Always point the sharp end away from your body.
- **Brush:**
 - Ensure the brush is free from debris before use. Dispose of any used brushes properly.
- **Column Spring Lifter:**
 - Use this tool carefully to avoid pinching fingers or hands.
- **Closure Nut Wrench:**
 - Ensure the wrench is securely fitted before applying force. Avoid overtightening, which may cause damage.

Instructions for Installation and Usage

1. Preparation:

- Gather all tools and components from the MEC Maintenance Kit.
- Ensure your work area is welllit and organized.

2. Using the AntiSeize Lubricant:

- Apply a small amount of lubricant to threads and moving parts of the reloader as needed.
- Wipe away any excess lubricant with a clean cloth.

3. Using the Pick:

- Carefully use the pick to clean any debris from tight spaces in the reloader.
- Avoid using excessive force to prevent damage to components.

4. Using the Brush:

- Use the brush to sweep away dust and particles from the reloader.
- Clean the brush after use and store it in the kit.

5. Using the Column Spring Lifter:

- Insert the lifter into the appropriate slot and gently lift the column spring.
- Ensure the spring is fully lifted before proceeding with maintenance.

6. Using the Closure Nut Wrench:

- Fit the wrench onto the closure nut and turn counterclockwise to loosen.
- After maintenance, retighten the nut securely but do not overtighten.

Disposal Instructions

- Dispose of any used materials, such as rags or brushes, in accordance with local regulations.
- Do not dispose of lubricants or chemicals down drains. Follow local hazardous waste disposal guidelines.

Contact Information for Further Support

For any safety inquiries or concerns regarding the MEC Maintenance Kit, please refer to the product packaging for the EU-based contact information. You can also check for any recall updates on the EU's Safety Gate platform.

Important Note: Always stay informed about safety guidelines and product recalls. Report any unsafe products or accidents to the appropriate authorities. Your safety is our priority.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at