

SINGLE STAGE PRESS STEEL SHOT CHARGE BAR - MEC RELOADING 7/8OZ #1-#4 SHOT SINGLE STAGE STEEL SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

This is a steel shot charge bar for single stage reloaders. Available to load from 7/8 oz. to 1-1/2 oz. of shot and #1 sizes down to #6.



Attributes

- Name: [MEC RELOADING 7/8OZ #1-#4 SHOT SINGLE STAGE STEEL SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019390
- Mfr. No.: 30207814
- Delivery weight: 0.238kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489012928

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for SINGLE STAGE PRESS STEEL SHOT CHARGE BAR
- About Us

Safety Instruction Guide for SINGLE STAGE PRESS STEEL SHOT CHARGE BAR

Introduction

Thank you for choosing the SINGLE STAGE PRESS STEEL SHOT CHARGE BAR by MEC RELOADING. This guide provides essential safety instructions and guidelines for the safe use of your product. Please read this document carefully to ensure safe operation and handling.

General Safety Guidelines

- Always use the charge bar according to the manufacturer's instructions.
- Ensure that the charge bar is compatible with your specific reloading press model.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the charge bar for any signs of wear or damage before use.
- Do not modify the charge bar in any way, as this may compromise safety.
- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when reloading.

Specific Safety Precautions for Use

- Ensure the workspace is clean and free of any obstructions before reloading.
- Do not overload the charge bar beyond its specified capacity (7/8 oz. to 11/2 oz. of shot).
- Only use recommended shot sizes (#1 to #6) for safe operation.
- Avoid using the charge bar if you notice any unusual noises or resistance during operation.
- Store the charge bar in a dry, cool place to prevent rust and degradation.
- Always follow local regulations regarding the use and storage of reloading equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing charge bar from the press.
- Align the SINGLE STAGE PRESS STEEL SHOT CHARGE BAR with the mounting points on your reloading press.
- Secure the charge bar in place according to the manufacturer's instructions.

2. Usage:

- Set the desired weight of shot to be loaded on the charge bar.
- Check that the charge bar is properly calibrated before proceeding.
- Fill the charge bar with the appropriate shot size.
- Operate the reloading press according to its instructions, ensuring the charge bar functions smoothly.
- After reloading, clean the charge bar to maintain its condition.

Disposal Instructions

- Dispose of the charge bar in accordance with local regulations regarding metal recycling.
- If the product is damaged beyond repair, contact your local waste management service for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or support, please contact the designated EU contact point for this product. Ensure you have the product details handy for reference.

By following these safety instructions, you can ensure a safe and effective reloading experience with your SINGLE STAGE PRESS STEEL SHOT CHARGE BAR. Always prioritize safety and adhere to the guidelines provided. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk