

SHELLHOLDER - MEC RELOADING 10 GAUGE SHELLHOLDER

[Reloading](#) > [Shellholders & Shellplates](#)

Shotgun shellholders for MEC reloading presses.



Attributes

- Name: [MEC RELOADING 10 GAUGE SHELLHOLDER](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019472
- Mfr. No.: 71510
- Cartridge: 10 Gauge
- Style: Press Type
- Delivery weight: 0.036kg
- Shipping height: 8mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489012539

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for SHELLHOLDER MEC RELOADING 10 GAUGE SHELLHOLDER](#)
- [About Us](#)

Safety Instruction Guide for SHELLHOLDER MEC RELOADING 10 GAUGE SHELLHOLDER

Introduction

Thank you for choosing the SHELLHOLDER MEC RELOADING 10 GAUGE SHELLHOLDER. This product is designed for use with MEC reloading presses to assist in the safe and efficient reloading of shotgun shells. Please read this safety instruction guide thoroughly before use to ensure safe handling and operation.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when reloading.
- Keep the work area clean and free from clutter to avoid accidents.
- Store the shellholder in a dry, cool place away from direct sunlight when not in use.
- Regularly inspect the shellholder for any signs of wear or damage.
- Follow all local laws and regulations regarding ammunition reloading.

Specific Safety Precautions for Use

- Do not exceed the recommended load specifications for the 10 gauge shells.
- Ensure that the reloading press is securely mounted and stable before use.
- Keep hands and body clear of the reloading mechanism during operation.
- Avoid distractions while reloading to maintain focus and prevent accidents.
- Do not allow children or unauthorized individuals to operate the reloading equipment.
- If you experience any issues during reloading, stop immediately and assess the situation.

Instructions for Installation and Usage

1. Installation:

- Ensure that the MEC reloading press is turned off and unplugged before installation.
- Locate the appropriate mounting area on the reloading press.
- Securely attach the SHELLHOLDER MEC RELOADING 10 GAUGE SHELLHOLDER to the press according to the manufacturer's instructions.
- Doublecheck that the shellholder is firmly in place before proceeding.

2. Usage:

- Prepare your workspace by gathering all necessary materials and tools.
- Load the 10 gauge shells into the shellholder as per the instructions provided with your reloading press.
- Follow the reloading press instructions for operating the machine safely.
- Monitor the reloading process and ensure that no obstructions are present in the mechanism.

Disposal Instructions

- Dispose of any unused or expired components of the reloading process according to local regulations.
- Do not throw away hazardous materials in regular trash. Check local guidelines for proper disposal of hazardous waste.
- Ensure that the shellholder and any associated tools are cleaned and stored properly to prolong their life.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the contact information provided by the manufacturer. Ensure that you have the product details ready for a more efficient response.

Thank you for following these safety instructions. Your safety is our priority. Enjoy reloading with the SHELLHOLDER MEC RELOADING 10 GAUGE SHELLHOLDER responsibly and safely.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk