

SHELLHOLDER - MEC RELOADING 12 GAUGE SHELLHOLDER

[Reloading](#) > [Shellholders & Shellplates](#)

Shotgun shellholders for MEC reloading presses.



Attributes

- Name: [MEC RELOADING 12 GAUGE SHELLHOLDER](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019473
- Mfr. No.: 71512
- Cartridge: 12 Gauge
- Style: Press Type
- Delivery weight: 0.036kg
- Shipping height: 8mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489017183

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for SHELLHOLDER MEC RELOADING 12 GAUGE SHELLHOLDER](#)
- [About Us](#)

Safety Instruction Guide for SHELLHOLDER MEC RELOADING 12 GAUGE SHELLHOLDER

Introduction

Thank you for choosing the SHELLHOLDER MEC RELOADING 12 GAUGE SHELLHOLDER. This product is designed for use with MEC reloading presses to safely hold shotgun shells during the reloading process. This guide provides essential safety information, usage instructions, and contact details for further support to ensure a safe and effective reloading experience.

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Use the product only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for wear or damage before each use.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the SHELLHOLDER is compatible with your MEC reloading press model.
- Do not exceed the manufacturer's recommended capacity for the shellholder.
- Always wear appropriate safety gear, including safety glasses and hearing protection, when reloading.
- Keep your workspace clean and organized to prevent accidents.
- Avoid distractions while using the shellholder to maintain focus and ensure safety.
- Do not use the shellholder if it is damaged or malfunctioning.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is unplugged and not in operation.
- Align the shellholder with the designated mounting area on the MEC reloading press.
- Secure the shellholder using the provided screws or fasteners, ensuring it is tightly fitted.
- Doublecheck that the shellholder is properly installed before proceeding.

2. Usage

- Load the shotgun shells into the shellholder, ensuring they are seated correctly.
- Follow the MEC reloading press instructions for the reloading process.
- Monitor the reloading operation to ensure that shells are being processed correctly.
- After use, remove any remaining shells from the shellholder and clean as necessary.

Disposal Instructions

- Dispose of the shellholder according to local regulations for nonhazardous materials.
- If the shellholder is damaged beyond repair, consider contacting the manufacturer for recycling options.
- Do not dispose of the shellholder in regular household waste if it contains any hazardous materials.

Contact Information for Further Support

For any inquiries or safety concerns regarding the SHELLHOLDER MEC RELOADING 12 GAUGE SHELLHOLDER, please refer to the manufacturer's official website or customer service channels for assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with the SHELLHOLDER MEC RELOADING 12 GAUGE SHELLHOLDER. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk