

DISCONNECTOR/SEAR SPRING FOR RUGER 10/22

[Rifle Parts](#) > [Triggers Parts](#) > [Sear Parts](#) > [Sear Springs](#)

FITS: 10/22® - Common Parts, .22; M-96®, .22, .22 Mag, .44 Mag



Attributes

- Name: [DISCONNECTOR/SEAR SPRING FOR RUGER 10/22](#)
- Manufacturer: [RUGER](#)
- Product no.: 780010016
- Mfr. No.: B24
- Make: Ruger
- Model: 10/22
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DISCONNECTOR/SEAR SPRING FOR RUGER 10/22
- About Us

Safety Instruction Guide for DISCONNECTOR/SEAR SPRING FOR RUGER 10/22

Introduction

Thank you for choosing the DISCONNECTOR/SEAR SPRING for your RUGER 10/22. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of this product. Please read this manual carefully before use.

General Safety Guidelines

- Ensure that the product is suitable for your firearm model (RUGER 10/22).
- Always handle firearms safely and responsibly.
- Store the product in a secure location, away from children and unauthorized users.
- Regularly inspect the product for wear and damage before use.
- Follow all local laws and regulations regarding firearm modifications and safety.

Specific Safety Precautions for Use

- Use only with compatible firearms as specified.
- Do not attempt to modify or alter the DISCONNECTOR/SEAR SPRING.
- Always wear appropriate safety gear when handling firearms.
- Ensure the firearm is unloaded before installation or maintenance.
- Be aware of your surroundings and ensure that no one is in the vicinity when handling firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (e.g., screwdriver, pliers).

2. Installation Steps:

- Remove the firearm's action from the stock according to the manufacturer's instructions.
- Locate the existing sear spring in the firearm.
- Carefully remove the old sear spring, taking note of its orientation.
- Install the new DISCONNECTOR/SEAR SPRING in the same orientation as the old one.
- Reassemble the firearm, ensuring all parts are securely in place.

3. PostInstallation Checks:

- Conduct a function check to ensure proper operation.
- Verify that the firearm operates safely and correctly before use.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any questions or concerns regarding the DISCONNECTOR/SEAR SPRING, please refer to the manufacturer's contact information provided on the packaging or visit the manufacturer's website for further assistance.

By following these guidelines, you can help ensure your safety and the safe operation of your firearm. Always prioritize safety and responsibility when handling firearms and their components.

About Us

Brownells France

Brownells France - Le plus grand fournisseur d'Accessoires pour le tir, Pièces détachées & Outils d'Armurier

www.brownells.fr