

DISCONNECTOR & TRIGGER PIVOT PIN

[Handgun Parts](#) > [Trigger Group Parts](#) > [Disconnecter Parts](#) > [Disconnecter Pins](#)

FITS: Bisley‡ - Common Parts; New Model Blackhawk®; Redhawk® - Common Parts; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®; 10/22® - Common Parts, .22



Attributes

- Name: [DISCONNECTOR & TRIGGER PIVOT PIN](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012010
- Mfr. No.: KE02800
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for DISCONNECTOR & TRIGGER PIVOT PIN
- About Us

Safety Instruction Guide for DISCONNECTOR & TRIGGER PIVOT PIN

Introduction

Thank you for choosing the DISCONNECTOR & TRIGGER PIVOT PIN, designed specifically for various Ruger firearm models. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of this product. Please read this document carefully before use.

General Safety Guidelines

- Ensure the product is compatible with your firearm model before installation.
- Always follow the manufacturer's instructions for your firearm.
- Keep this product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the relevant authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Before handling the product, ensure your firearm is unloaded and pointed in a safe direction.
- Wear appropriate safety gear, including eye protection, during installation.
- Do not attempt to modify or alter the DISCONNECTOR & TRIGGER PIVOT PIN.
- Inspect the product for any signs of damage or wear before installation. Do not use damaged parts.
- Handle the product with care to avoid injury or accidents.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is completely unloaded.
- Gather the necessary tools for installation, including a punch tool and hammer.

2. Installation Steps:

- Remove the existing disconnector and trigger pivot pin from your firearm.
- Align the new DISCONNECTOR & TRIGGER PIVOT PIN with the mounting holes.
- Gently tap the pin into place using the punch tool and hammer, ensuring it is securely seated.
- Doublecheck that the pin is properly installed and does not protrude excessively.

3. PostInstallation Check:

- After installation, perform a function check of your firearm to ensure it operates correctly.
- Verify that the disconnector and trigger function as intended without any obstruction.

4. Usage:

- Always follow safe handling practices when operating your firearm.
- Regularly inspect the DISCONNECTOR & TRIGGER PIVOT PIN for signs of wear or damage.

Disposal Instructions

- Dispose of any old or unused parts in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, contact your local waste management

authority for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the DISCONNECTOR & TRIGGER PIVOT PIN, please refer to the manufacturer's website or contact your local dealer for assistance.

By following these safety instructions, you can help ensure the safe and effective use of the DISCONNECTOR & TRIGGER PIVOT PIN. Thank you for your attention to safety.

About Us

Brownells France

Brownells France - Le plus grand fournisseur d'Accessoires pour le tir, Pièces détachées & Outils d'Armurier

www.brownells.fr