

10/22® DROP-IN TRIGGER ASSEMBLY - TIMNEY 10/22® DROP-IN TRIGGER ASSEMBLY, BLACK

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

The Timney 10/22® trigger will undoubtedly set the standard for the future of aftermarket trigger upgrades for the Ruger® 10-22®. Featuring a one piece action of CNC machined 6061-T6 aircraft grade billet aluminum the Timney trigger for the Ruger® 10-22® is a complete action replacement. The trigger, sear, and hammer are wire EDM cut and heat treated steel for exceptional durability. Push out the two action pins and "drop in" the Timney complete trigger assembly. The Timney 10-22® trigger features a Timney designed extended magazine release that can be operated by one finger for exceptional ease and accessibility. It also comes standard with an auto bolt release. As with all the Timney triggers made in the U.S.A. each complete action replacement is hand assembled, calibrated and tested for a lifetime of reliable service. The trigger is set at 2 pounds from the factory, with no creep.



The Timney 10/22® trigger will undoubtedly set the standard for the future of aftermarket trigger upgrades for the Ruger® 10-22®. Featuring a one piece action of CNC machined 6061-T6 aircraft grade billet aluminum the Timney trigger for the Ruger® 10-22® is a complete action replacement. The trigger, sear, and hammer are wire EDM cut and heat treated steel for exceptional durability. Push out the two action pins and "drop in" the Timney complete trigger assembly. The Timney 10-22® trigger features a Timney designed extended magazine release that can be operated by one finger for exceptional ease and accessibility. It also comes standard with an auto bolt release. As with all the Timney triggers made in the U.S.A. each complete action replacement is hand assembled, calibrated and tested for a lifetime of reliable service. The trigger is set at 2.75 pounds from the factory, with no creep.

Attributes

- Name: [TIMNEY 10/22® DROP-IN TRIGGER ASSEMBLY, BLACK](#)
- Manufacturer: [TIMNEY](#)
- Product no.: 883000038
- Mfr. No.: 1022-1C
- Model: 10/22
- Style: -
- Weapon type: Ruger
- Delivery weight: 0.204kg
- Shipping height: 36mm
- Shipping width: 99mm
- Shipping length: 157mm
- UPC: 081950102211

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Timney 10/22® DropIn Trigger Assembly Safety Instruction Guide
- About Us

Timney 10/22® DropIn Trigger Assembly Safety Instruction Guide

Introduction

Thank you for choosing the Timney 10/22® DropIn Trigger Assembly. This product is designed to enhance the performance of your Ruger® 10/22® firearm. Please read this safety instruction guide carefully to ensure safe and proper use of the trigger assembly. This guide complies with the EU General Product Safety Regulation (GPSR) to provide you with essential safety information.

General Safety Guidelines

- Ensure that the firearm is unloaded before installing or handling the trigger assembly.
- Always handle firearms with care, treating them as if they are loaded.
- Keep the trigger assembly out of reach of children and unauthorized users.
- Inspect the trigger assembly for any visible damage or defects before installation.
- Follow all local laws and regulations regarding firearm modifications.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

• Installation Precautions:

- Only install the trigger assembly in a Ruger® 10/22® firearm.
- Use appropriate tools to avoid damaging the trigger assembly during installation.

• Usage Precautions:

- Do not modify the trigger assembly or firearm in any manner that may compromise safety.
- Ensure that the trigger is properly set at 2.75 pounds from the factory before use.
- Regularly check the trigger assembly for wear and tear.

• Handling Precautions:

- Always keep the firearm pointed in a safe direction.
- Never place your finger on the trigger until you are ready to shoot.
- Be aware of your surroundings and ensure that the area is clear before firing.

Instructions for Installation and Usage

1. Installation Steps:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Push out the two action pins from the Ruger® 10/22® receiver.
- Carefully remove the existing trigger assembly.
- Align the Timney 10/22® trigger assembly with the receiver and insert it.
- Push the action pins back into place to secure the assembly.
- Test the trigger for proper function before using the firearm.

2. Usage Steps:

- Load the firearm according to the manufacturer's instructions.

- Use the Timney designed extended magazine release with one finger for ease of access.
- Ensure the auto bolt release functions correctly before firing.
- After firing, always check the trigger assembly for any signs of malfunction or wear.

Disposal Instructions

- Dispose of the trigger assembly in accordance with local regulations.
- If the product is damaged or no longer in use, ensure that it is securely packaged to prevent accidental discharge.
- Do not dispose of the trigger assembly in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Timney 10/22® DropIn Trigger Assembly, please refer to the manufacturer's website or contact their customer support. Ensure that you have your product details ready for any inquiries.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your Timney 10/22® DropIn Trigger Assembly. Thank you for prioritizing safety in your firearm usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk