

RUGER PRECISION RIFLE 2 STAGE TRIGGERS - TIMNEY RUGER PRECISION RIFLE 2 STAGE TRIGGER CURVED

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Timney offers this 2 stage trigger for the Ruger Precision Rifle. The pull weight is factory calibrated for an eight-ounce first stage and one -pound second stage (the second stage is adjustable from 8-ounces to 2.5 pounds of pull weight) The 2-Stage trigger features machined and hardened steel work surfaces and the sears are Teflon-nickel coated for added lubricity. The trigger housing and shoe are CNC machined using state-of-the-art robotics and the sears are EDM cut from high-grade solid steel. The trigger housing utilizes an anodized aluminum body and the trigger shoe and safety are carbonitrided which dramatically increases the surface hardness and wear-resistance properties of the metal. Does Not fit the rimfire Ruger Precision Rifles.



Attributes

- Name: [TIMNEY RUGER PRECISION RIFLE 2 STAGE TRIGGER CURVED](#)
- Manufacturer: [TIMNEY](#)
- Product no.: 883000106
- Mfr. No.: 650
- Model: Precision Rifle
- Style: 2-Stage
- Weapon type: Ruger
- Delivery weight: 0.104kg
- Shipping height: 25mm
- Shipping width: 89mm
- Shipping length: 191mm
- UPC: 081950650002

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Timney Ruger Precision Rifle 2 Stage Trigger](#)
- [About Us](#)

Safety Instruction Guide for Timney Ruger Precision Rifle 2 Stage Trigger

Introduction

Thank you for choosing the Timney Ruger Precision Rifle 2 Stage Trigger. This guide provides essential safety information to ensure the safe use and installation of your new trigger. Please read this guide carefully and keep it for future reference.

General Safety Guidelines

- Ensure that the trigger is installed by a qualified gunsmith or an experienced individual familiar with firearm modifications.
- Always treat firearms as if they are loaded.
- Keep firearms pointed in a safe direction at all times.
- Store firearms and ammunition securely, out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure a safe shooting environment.
- Regularly inspect your firearm and trigger for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm modifications and usage.

Specific Safety Precautions for Use

- **Potential Hazards:** The use of the Timney Ruger Precision Rifle 2 Stage Trigger may involve risks such as accidental discharge or malfunction if not installed or used correctly.
- **Avoiding Hazards:**
 - Never attempt to modify or disassemble the trigger beyond the manufacturer's specifications.
 - Ensure that the firearm is unloaded before installing or adjusting the trigger.
 - Do not use the trigger if it shows any signs of damage or malfunction.
 - Ensure proper installation to avoid misalignment, which can lead to unsafe conditions.
- **Age Specific Warnings:** This product is not intended for use by individuals under the legal age for firearm ownership in your jurisdiction. Ensure that all users are trained and knowledgeable about firearm safety.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is completely unloaded before beginning installation.
- Follow the manufacturer's instructions for installing the Timney Ruger Precision Rifle 2 Stage Trigger.
- Use the appropriate tools and safety equipment during installation.
- If unsure, consult a qualified gunsmith for assistance.

2. Usage:

- Familiarize yourself with the trigger's functions and adjustments before using it in the field.
- Practice safe handling and shooting techniques at all times.
- Adjust the second stage pull weight only if you are confident in your ability to do so safely.
- Regularly check the trigger for proper function and adjust as necessary.

Disposal Instructions

- Dispose of the trigger responsibly and in accordance with local regulations.
- If the trigger is damaged or no longer in use, consult local waste management guidelines for proper disposal methods.
- Do not dispose of the trigger in regular household waste.

Contact Information for Further Support

For any inquiries or concerns regarding the Timney Ruger Precision Rifle 2 Stage Trigger, please refer to the manufacturer's contact details provided with your product packaging or visit the official website for further assistance.

Thank you for prioritizing safety in your firearm practices. Enjoy your shooting experience with the Timney Ruger Precision Rifle 2 Stage Trigger.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk