

1911 SMOOTH MAINSPRING HOUSING - WILSON COMBAT 1911 MAINSPRING HOUSING, SMOOTH, BLUED

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Housings](#)

The addition of this Mainspring Housing is a great way to improve the grip and appearance of your 1911 Auto. You'll be amazed at the quality of this part. It's fully machined from bar stock with a smooth blue or stainless steel finish.



Attributes

- Name: [WILSON COMBAT 1911 MAINSPRING HOUSING, SMOOTH, BLUED](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 965000203
- Mfr. No.: 92FS
- Finish: Blued
- Model: Commander, Government
- Weapon type: 1911
- Shipping height: 10mm
- Shipping width: 89mm
- Shipping length: 119mm
- UPC: 811826020062

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Smooth Mainspring Housing
- About Us

Safety Instruction Guide for 1911 Smooth Mainspring Housing

Introduction

Thank you for choosing the 1911 Smooth Mainspring Housing by Wilson Combat. This guide provides important safety information and instructions to ensure the safe use and installation of your product. Please read this guide carefully before using the mainspring housing.

General Safety Guidelines

- Ensure that all safety precautions are followed during installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the mainspring housing for any signs of wear or damage.
- Do not use the mainspring housing if it appears damaged or defective.
- Always adhere to local laws and regulations regarding firearm accessories.

Specific Safety Precautions for Use

- Use only with compatible 1911 Government and Commander models.
- Ensure that the firearm is unloaded before installation or maintenance.
- Always handle firearms with care and follow basic gun safety rules.
- Do not modify the mainspring housing in any way.
- Wear appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

Installation Steps

1. **Preparation:** Ensure that the firearm is completely unloaded. Remove the magazine and check the chamber.
2. **Remove Old Mainspring Housing:**
 - Use a punch to drive out the mainspring housing pin.
 - Carefully remove the old mainspring housing from the grip.
3. **Install New Mainspring Housing:**
 - Align the new mainspring housing with the grip.
 - Insert the mainspring housing into the grip and secure it in place.
 - Reinsert the mainspring housing pin and ensure it is fully seated.
4. **Final Check:** Doublecheck that the mainspring housing is securely in place and that the firearm is still unloaded.

Usage Guidelines

- After installation, check the functionality of the firearm before use.
- Regularly inspect the mainspring housing for any signs of wear or misalignment.
- If any issues arise, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of the packaging and any old parts in accordance with local waste disposal regulations.
- If the mainspring housing becomes damaged beyond use, consult local regulations for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the 1911 Smooth Mainspring Housing, please consult your retailer or refer to the manufacturer's website for additional support.

Conclusion

By following the safety guidelines and instructions outlined in this guide, you can ensure the safe use of your 1911 Smooth Mainspring Housing. Always prioritize safety and compliance with local laws when handling firearms and their accessories. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk