

1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS - WILSON COMBAT FIRING PIN SPRING

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Springs](#)

Quality Parts Meet Or Exceed Factory Specs

"Just like original" parts for building a 1911 Auto or returning a gun to factory specifications.



Attributes

- Name: [WILSON COMBAT FIRING PIN SPRING](#)
- Manufacturer: [WILSON COMBAT](#)
- Product no.: 965011120
- Mfr. No.: R12
- Model: Commander, Government, Officers
- Weapon type: 1911
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 874218002947

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS
- About Us

Safety Instruction Guide for 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS

Introduction

Thank you for choosing the 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS by Wilson Combat. This product is designed to provide reliable performance for your 1911 Auto firearm. Please read this safety instruction guide carefully to ensure safe use and compliance with EU safety regulations.

General Safety Guidelines

- Ensure that all firearms are handled with care and respect.
- Always treat every firearm as if it is loaded.
- Keep firearms out of reach of children and unauthorized users.
- Use only compatible parts for your specific firearm model.
- Regularly inspect your firearm and its components for wear or damage.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Only use the 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS with the following models:
 - Government
 - Commander
 - Officers
- Ensure that your firearm is unloaded before installation or maintenance.
- Wear safety glasses when working with firearms to protect your eyes.
- Avoid using damaged or worn parts, as they may create safety hazards.
- Follow all local laws and regulations regarding firearm modifications and usage.

Instructions for Installation and Usage

1. Preparation

- Ensure your workspace is clean and free from distractions.
- Gather all necessary tools and safety equipment.

2. Installation Steps

- Verify that the firearm is unloaded and that the magazine is removed.
- Disassemble your 1911 Auto according to the manufacturer's instructions.
- Remove the old firing pin spring and inspect the area for any debris.
- Install the new 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS in the appropriate position.
- Reassemble the firearm, ensuring all components are securely fitted.

3. PostInstallation Check

- Conduct a function check to ensure the firearm operates correctly.
- Store the firearm in a safe and secure location.

4. Usage

- Always follow safe handling practices when using your firearm.

- Regularly check the firing pin springs for signs of wear or damage.
- Replace the firing pin springs as necessary to maintain optimal performance.

Disposal Instructions

- Dispose of old or damaged firing pin springs in accordance with local regulations.
- Do not dispose of firearm components in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any questions or concerns regarding the 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS, please refer to the manufacturer's support resources. Ensure that you have your product information and any relevant details ready for assistance.

By following these guidelines and instructions, you can ensure the safe use of your 1911 AUTO "FACTORY PLUS" FIRING PIN SPRINGS and maintain compliance with EU safety regulations. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk