

# BERETTA 92/96 RECOIL GUIDE ROD - WOLFF SILVER

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

## Superior Support & Smooth Cycling

Full-length, hardened steel guide rod helps prevent spring bind and improves cycling. Replaces the soft, factory, plastic part for smooth, reliable function without galling or binding. Machined from solid steel, polished, then hardened.



## Attributes

- Name: [WOLFF SILVER](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969000078
- Mfr. No.: 32716
- Model: 92,96
- Weapon type: Beretta
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 64mm
- Shipping length: 191mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER Safety Instruction Guide
- About Us

# BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER Safety Instruction Guide

## Introduction

Thank you for choosing the BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER. This guide provides essential safety instructions and guidelines for the safe installation and use of this product. Please read this document carefully to ensure safe and effective operation.

## General Safety Guidelines

- Ensure you are familiar with the operation of your firearm and its components before using the recoil guide rod.
- Always handle firearms with care and follow all safety protocols.
- Store this product in a safe location, away from children and unauthorized users.
- Inspect the recoil guide rod regularly for signs of wear or damage.
- If you notice any defects or issues, discontinue use immediately and consult a professional.

## Specific Safety Precautions for Use

- Do not use the recoil guide rod if it is damaged or shows signs of wear.
- Always ensure that the firearm is unloaded before installing or removing the guide rod.
- Use only compatible Beretta models (92 and 96) for installation.
- Follow the manufacturer's instructions for your specific firearm model to avoid improper installation.
- Wear appropriate safety gear, including eye protection, when working with firearms.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, including a punch tool if required.

### 2. Installation Steps

- Remove the factory plastic guide rod from your Beretta 92 or 96.
- Insert the new BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER into the recoil spring assembly.
- Ensure the guide rod is properly seated and aligned.
- Reassemble the firearm according to the manufacturer's instructions.

### 3. Usage

- After installation, test the firearm in a safe environment to ensure proper function.
- Monitor the performance of the guide rod during use and check for any unusual sounds or malfunctions.

## Disposal Instructions

- Dispose of the old factory plastic guide rod according to local regulations for plastic waste.
- If the new recoil guide rod becomes damaged beyond repair, consult local regulations for the disposal of metal components.

## **Contact Information for Further Support**

For safety inquiries or support regarding the BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER, please refer to the manufacturer's customer service resources or consult your local dealer.

By following these instructions and guidelines, you can ensure the safe use and longevity of your BERETTA 92/96 RECOIL GUIDE ROD WOLFF SILVER. Thank you for your attention to safety.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)