

TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS - 11 LB. SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Fine Tune For Light, Standard Or Heavy Loads

Like all Wolff springs, these for the 1911 Auto in .45, .38 Super or 9mm are the finest, most reliable, longest lasting ones available. The springs of choice for most of the nation's top builders. Except where noted, all recoil springs are supplied with an extra power firing pin spring that keeps the firing pin stop in place and prevents firing pin float ; an addition recommended by pistolsmith Bill Wilson. TYPE A - For Target (Softball) Loads were originally recommended to us by Major F. B. Conway, U.S.A. - M.T.U. Whenever lighter than standard bullets or powder charges are being used, a lighter recoil spring is a must for correct functioning; however, they MUST NOT BE USED WITH STANDARD (HARDBALL) LOADS. The 10 lb. Type A spring is the old favorite (for reduced loads) and for that reason we also make it available as a single item (without the extra power firing pin spring).



Attributes

- Name: [11 LB. SPRING](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969419110
- Mfr. No.: 41911
- Make: 1911
- Model: Government
- Pounds: 11 lbs
- Delivery weight: 0.018kg
- Shipping height: 10mm
- Shipping width: 86mm
- Shipping length: 224mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS 11 LB. SPRING
- About Us

Safety Instruction Guide for TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS 11 LB. SPRING

Introduction

Thank you for purchasing the TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS 11 LB. SPRING by WOLFF. This guide provides important safety instructions and usage information to ensure the safe and effective operation of your recoil spring. Please read this guide carefully before use.

General Safety Guidelines

- Ensure safe use of the recoil spring by following all instructions outlined in this guide.
- This product is designed for specific use with the 1911 Auto in .45, .38 Super, or 9mm calibers.
- The recoil spring should only be used with target (softball) loads. It must not be used with standard (hardball) loads.
- Always handle firearms and firearm components with care and in accordance with local laws and regulations.
- Keep the recoil spring and all firearm components out of reach of children and unauthorized users.

Specific Safety Precautions for Use

- **Compatibility:** Ensure that the recoil spring is compatible with your firearm model (1911 Auto).
- **Installation:** Follow the installation instructions carefully to avoid improper fitting, which could lead to malfunction.
- **Usage:** Use the recoil spring only with lighter than standard bullets or powder charges. Using it with standard loads can cause damage or injury.
- **Inspection:** Regularly inspect the recoil spring for wear and tear. Replace if any signs of damage are observed.
- **Training:** Ensure that users are trained in the safe handling and operation of firearms.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the old recoil spring from the firearm according to the manufacturer's instructions.
- Insert the TYPE A recoil spring into the recoil spring guide, ensuring it is properly seated.
- Reassemble the firearm carefully, paying attention to all components.

2. Usage:

- Load only target (softball) loads into the firearm.
- Verify that the firing pin stop is secured in place with the extra power firing pin spring included with the recoil spring.
- Test the firearm in a safe and controlled environment to ensure proper functioning.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations for metal and firearm components.
- Do not dispose of the recoil spring in regular household waste.
- Consider recycling options to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS 11 LB. SPRING, please refer to the manufacturer's contact information provided with the product packaging or visit their official website for additional support.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe and effective use of your TYPE A RECOIL SPRING FOR TARGET (SOFTBALL) LOADS 11 LB. SPRING. Always prioritize safety and responsible firearm handling.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at