

Constrictor Ratchet Tree Mount

[Shooting Accessories](#) > [Range Gear](#) > [Cameras](#)

With the release of the BOG camera lineup, BOG is introducing a full assortment of game camera accessories. The Ratchet Game Camera Mount gives hunters the ability to mount their cameras without damaging trees. The mini ball head allows the camera to be angled at nearly any angle to capture that perfect image.

NO IMAGE
AVAILABLE

Attributes

- Name: [BOG Constrictor Ratchet Tree Mount](#)
- Manufacturer: [BOG](#)
- Product no.: EU1001649
- Mfr. No.: 1112786
- Color: Black/Silver
- Delivery weight: 0.45kg
- Shipping height: 191mm
- Shipping width: 70mm
- Shipping length: 279mm
- UPC: 661120080435

Table of Contents

- [Startpage](#)
- [BOG Constrictor Ratchet Tree Mount Safety Instructions](#)
- [About Us](#)

BOG Constrictor Ratchet Tree Mount Safety Instructions

Introduction

Thank you for choosing the BOG Constrictor Ratchet Tree Mount. This product is designed to help you securely mount your game camera without causing damage to trees. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's instructions.
- Inspect the product for any visible damage before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as described in this manual.
- Report any unsafe products or incidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the Ratchet Tree Mount is securely fastened before attaching your camera.
- Do not exceed the weight limit recommended by the manufacturer for the camera being mounted.
- Avoid mounting the camera on trees that show signs of decay or instability.
- Be cautious of your surroundings when working at height; ensure the area is clear of obstacles.
- Always use proper safety gear when climbing or working in elevated positions.

Instructions for Installation and Usage

Installation Steps

1. **Select a Suitable Tree:** Choose a healthy, sturdy tree that can support the weight of your camera and the mount.
2. **Prepare the Mount:** Unpack the BOG Constrictor Ratchet Tree Mount and ensure all components are included and undamaged.
3. **Attach the Mount:**
 - Position the mount around the tree at the desired height.
 - Use the ratchet mechanism to secure the mount tightly against the tree. Ensure it is firmly in place.
4. **Attach Your Camera:**
 - Use the mini ball head to adjust the camera angle as needed.
 - Ensure the camera is securely attached to the mount before use.

Usage Guidelines

- Regularly check the mount and camera to ensure they remain secure during use.
- Adjust the camera angle as necessary to capture the best images.
- After use, carefully remove the camera and disassemble the mount if no longer needed.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling where possible to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding the BOG Constrictor Ratchet Tree Mount, please refer to the manufacturer's official website or contact their customer service for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with the BOG Constrictor Ratchet Tree Mount. Thank you for your attention to safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at