

Shotgun Chamber Flag - Basic

[Shooting Accessories](#) > [Training & Safety Gear](#) > [Chamber Safety Flags](#)

Bright Neon green chamber flags to easily identify an unloaded firearm.

NO IMAGE
AVAILABLE

Attributes

- Name: [Shotgun Chamber Flag - Basic](#)
- Manufacturer: [Brownells Europe](#)
- Product no.: EU2011997
- Mfr. No.: EU2011997
- Colour: Neon Green
- Delivery weight: 0.1kg

Table of Contents

- Startpage
- Shotgun Chamber Flag Safety Instructions
- About Us

Shotgun Chamber Flag Safety Instructions

Introduction

Thank you for purchasing the Shotgun Chamber Flag. This product is designed to help ensure the safe handling and storage of shotguns by providing a clear visual indication of an unloaded firearm. Please read this guide carefully to understand how to use the chamber flag safely and effectively.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Ensure that the shotgun is pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Store firearms and ammunition separately and securely.
- Use chamber flags to indicate that a firearm is unloaded.
- Regularly check for updates on safety recalls and product alerts.

Specific Safety Precautions for Use

- Only use the chamber flag with shotguns.
- Do not remove the chamber flag until you are ready to use the firearm.
- Ensure the chamber flag is fully inserted into the chamber.
- Do not rely solely on the chamber flag for safety; always follow safe firearm handling practices.
- Keep chamber flags out of reach of children and unauthorized users.

Instructions for Installation and Usage

1. **Check the Firearm:** Before using the chamber flag, ensure that the shotgun is completely unloaded. Check the chamber, magazine, and any other compartments.
2. **Insert the Chamber Flag:**
 - Open the action of the shotgun.
 - Insert the chamber flag into the chamber until it is fully seated.
 - Close the action of the shotgun, ensuring the chamber flag remains visible.
3. **Visual Inspection:** Ensure that the bright neon green color of the chamber flag is clearly visible, indicating that the firearm is unloaded.
4. **Storage:** When storing the shotgun, keep the chamber flag in place to prevent accidental loading.
5. **Removal:** When you are ready to use the shotgun, carefully remove the chamber flag before loading or firing.

Disposal Instructions

- Dispose of any damaged or worn chamber flags responsibly.
- Do not dispose of chamber flags in a manner that could pose a risk to others.
- Follow local regulations for the disposal of plastic products.

Contact Information for Further Support

For safety inquiries or further assistance, please refer to the relevant authorities or your local firearms safety organization. Always ensure you have access to appropriate resources for firearm safety.

By following these safety instructions, you contribute to a safer environment for yourself and others. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk