

Pistol Chamber Flag - Remove before pew pew

[Shooting Accessories](#) > [Training & Safety Gear](#) > [Chamber Safety Flags](#)

Bright Neon green chamber flags to easily identify an unloaded firearm.

NO IMAGE
AVAILABLE

Attributes

- Name: [Pistol Chamber Flag - Remove before pew pew](#)
- Manufacturer: [Brownells Europe](#)
- Product no.: EU2012006
- Mfr. No.: EU2012006
- Colour: Neon Green
- Delivery weight: 0.1kg

Table of Contents

- Startpage
- Pistol Chamber Flag Safety Instruction Guide
- About Us

Pistol Chamber Flag Safety Instruction Guide

Introduction

Thank you for choosing the Pistol Chamber Flag. This product is designed to enhance firearm safety by clearly indicating that a pistol is unloaded. It is essential to follow the safety guidelines and instructions outlined in this document to ensure safe usage.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Use the chamber flag only with unloaded firearms.
- Do not rely solely on the chamber flag; always check the firearm manually.
- Keep the chamber flag out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the firearm is pointed in a safe direction when inserting or removing the chamber flag.
- Only use the chamber flag in conjunction with firearms that are compatible with its design.
- Inspect the chamber flag regularly for any signs of wear or damage before use.
- Do not use the chamber flag if it appears to be damaged or defective.
- Always remove the chamber flag before handling or firing the firearm.

Instructions for Installation and Usage

1. Installation of the Chamber Flag:

- Open the action of the firearm.
- Insert the chamber flag into the chamber until it is fully seated.
- Ensure that the bright neon green portion is visible, indicating that the firearm is unloaded.

2. Usage of the Chamber Flag:

- Confirm that the firearm is unloaded before inserting the chamber flag.
- Use the chamber flag as a visual indicator during transport and storage.
- Remove the chamber flag before any handling or firing of the firearm.

3. Removal of the Chamber Flag:

- Open the action of the firearm.
- Carefully remove the chamber flag from the chamber.
- Store the chamber flag in a safe place when not in use.

Disposal Instructions

- Dispose of the chamber flag in accordance with local regulations.
- Do not dispose of the chamber flag in regular household waste if it is damaged.
- If the chamber flag is no longer needed, consider recycling it if applicable.

Contact Information for Further Support

For further assistance or inquiries regarding safety or product information, please refer to the manufacturer's website or contact your local distributor.

By following these guidelines, you can ensure the safe and effective use of your Pistol Chamber Flag. Your safety and the safety of those around you is our top priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk