

# Claymore Clay Target Thrower - Claymore Solo Clay Target Thrower

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

The Caldwell Claymore family of clay target throwers brings fun and innovation to shotgun shooting. The Claymore Solo is a compact, lightweight clay target thrower that offers several innovative features over the competition. A unique foot pedal design allows the Claymore Solo to tension the throwing arm spring and release the target in one smooth step, while keeping hands free and clear of the thrower. This foot pedal operation eliminates the need for a user to put themselves in harm's way while manually resetting the arm required by traditional thrower designs. The Claymore's arm automatically resets itself each time allowing the user to load a target while the arm has no spring tension applied. The Solo has quick, toolless launch angle adjustment to change the target path from straight away to practically vertical. The throwing arm is designed to work with standard, midi, and mini clay targets and can throw both singles and doubles. The Claymore Solo's folding legs reduce its footprint, making it easier to pack in the field and store in the garage when not in use. Get out and have some fun busting some clays with family and friends with the Caldwell Claymore Solo

NO IMAGE  
AVAILABLE

## Attributes

- Name: [Claymore Solo Clay Target Thrower](#)
- Manufacturer: [Caldwell](#)
- Product no.: EU2012257
- Mfr. No.: 4002777
- Colour: Black
- Style: Thrower
- Delivery weight: 11kg
- Shipping height: 279.4mm
- Shipping width: 355.6mm
- Shipping length: 801mm
- UPC: 661120750543

# Table of Contents

- Startpage
- Safety Instruction Guide for the Caldwell Claymore Solo Clay Target Thrower
- About Us

# Safety Instruction Guide for the Caldwell Claymore Solo Clay Target Thrower

## Introduction

Thank you for choosing the Caldwell Claymore Solo Clay Target Thrower. This guide provides important safety instructions, usage guidelines, and disposal information to ensure your safe and enjoyable experience with this product. Please read this guide carefully before using the Claymore Solo.

## General Safety Guidelines

- Ensure that all users read and understand these safety guidelines before operating the Claymore Solo.
- Always supervise children and inexperienced users when using the clay target thrower.
- Keep the area clear of bystanders during operation to prevent injury.
- Only use the product in a safe and designated shooting area.
- Regularly inspect the thrower for any signs of wear or damage. Do not use if damaged.
- Ensure that all safety features are functioning properly before each use.
- Follow all local laws and regulations regarding the use of clay target throwers.

## Specific Safety Precautions for Use

- Always keep hands and body clear of the throwing arm during operation.
- Do not attempt to manually reset the throwing arm while the foot pedal is engaged.
- Ensure that the foot pedal is fully released before attempting to load targets.
- Use only recommended clay targets (standard, midi, and mini) to avoid malfunctions.
- Avoid wearing loose clothing or jewelry that could get caught in the moving parts.
- Do not modify the thrower in any way, as this may compromise safety.
- Keep the thrower away from water and extreme weather conditions to prevent damage.

## Instructions for Installation and Usage

### Installation

1. **Unpack the Claymore Solo:** Carefully remove the thrower from the packaging.
2. **Inspect the Components:** Ensure all parts are included and undamaged.
3. **Set Up the Thrower:**
  - Position the thrower on a flat, stable surface.
  - Extend the folding legs to provide stability.
4. **Adjust the Launch Angle:**
  - Use the quick, toolless adjustment feature to set the desired launch angle.

### Usage

1. **Loading Targets:**
  - Ensure the throwing arm is in the reset position (no spring tension).
  - Place the clay target securely in the throwing arm.
2. **Operating the Thrower:**
  - Stand clear of the thrower and ensure no one is in the line of fire.
  - Press down on the foot pedal to tension the throwing arm and release the target.
3. **Resetting the Thrower:**
  - The throwing arm will automatically reset after each launch.
  - You may load another target while the arm is reset.

## Disposal Instructions

- Dispose of the Claymore Solo in accordance with local waste disposal regulations.
- Do not dispose of the thrower in household waste.
- If the product is no longer usable, consider recycling parts where possible.

## Contact Information for Further Support

For any questions or concerns regarding the Caldwell Claymore Solo, please refer to the manufacturer's website or contact their customer service for assistance.

By following these safety instructions, you can enjoy a safe and fun experience with the Caldwell Claymore Solo Clay Target Thrower. Always prioritize safety and be mindful of your surroundings while using this product.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)