

OBI Clamp Lock- w/Locking RIGHT WHT

[Shooting Accessories](#) > [Duty Gear](#)

The Clamp Lock W/Locking is a secure and versatile mounting solution, designed for ultimate stability and convenience when attaching gear to your backpack or belt strap.

1. Secure Bolted Attachment: Bolts directly to the strap, ensuring a rock-solid hold that won't shift or move.
2. Adjustable Tension Locking Lever: Equipped with a small lever to securely fasten posts into the Clamp Lock, providing enhanced stability.
3. Left & Right Options: Designed with both left and right configurations for easy access to the locking lever, regardless of how you mount it.
4. Wide Strap Compatibility: Works with straps ranging from 1/2 inch to 1.5 inches.
5. Flexible Orientation: Can be mounted vertically or horizontally for maximum adaptability.
6. MOLLE Compatible: Seamlessly integrates with MOLLE systems for added versatility.

NO IMAGE
AVAILABLE

Important: To use the Clamp Lock W/Locking, you will need at least one Clamp Lock OR Slide Lock, as well as an RP M, QD P, or Anywhere Mount.

The Clamp Lock W/Locking combines durability, flexibility, and convenience—perfect for securely mounting round or square posts to your gear.

Attributes

- Name: [OBI Clamp Lock- w/Locking RIGHT WHT](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2013638
- Mfr. No.: OBi01009-WHT
- Colour: White
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637840996

Table of Contents

- Startpage
- OBI Clamp Lock Safety Instruction Guide
- About Us

OBI Clamp Lock Safety Instruction Guide

Introduction

Thank you for choosing the OBI Clamp Lock with Locking Right. This product is designed to provide a secure and versatile mounting solution for your gear. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- **Product Safety:** The OBI Clamp Lock is designed to meet safety standards for nonfood products. Always ensure safe usage as outlined in this guide.
- **Enhanced Recalls:** Stay informed about any recalls. If a safety issue arises, follow the instructions provided in recall notices.
- **Online Shopping:** If purchased online, ensure that the retailer complies with safety requirements similar to those of physical stores.
- **Special Consumer Focus:** Extra care should be taken when using this product around children. Ensure that they do not play with or misuse the Clamp Lock.
- **EU Contact Point:** For safety inquiries, always refer to the provided contact information from the manufacturer or retailer.
- **Rapid Alerts:** Monitor the EU Safety Gate platform for updates on unsafe products.

Specific Safety Precautions for Use

- **Proper Use:** The OBI Clamp Lock is intended for mounting gear securely. Do not use it for any purpose other than its intended use.
- **Age Restrictions:** This product is not suitable for children under the age of 12 without adult supervision.
- **Inspection:** Before each use, inspect the Clamp Lock for any signs of wear or damage. Do not use if damaged.
- **Weight Limit:** Ensure that the total weight of the gear attached does not exceed the recommended limit for the Clamp Lock.
- **Secure Fastening:** Always ensure that the Adjustable Tension Locking Lever is securely fastened before use.
- **Avoid Overtightening:** Do not overtighten the bolts as this may damage the strap or the Clamp Lock.

Instructions for Installation and Usage

1. Gather Required Components:

- At least one Clamp Lock or Slide Lock.
- An RP M, QD P, or Anywhere Mount.

2. Installation:

- **Step 1:** Position the Clamp Lock on the desired strap location.
- **Step 2:** Use the provided bolts to attach the Clamp Lock securely to the strap. Ensure a rocksolid hold.
- **Step 3:** Adjust the Adjustable Tension Locking Lever to secure the posts into the Clamp Lock. Ensure it is tightly fastened for stability.
- **Step 4:** Choose the desired orientation (vertical or horizontal) for maximum adaptability.
- **Step 5:** Confirm that the Clamp Lock is securely mounted before attaching any gear.

3. Usage:

- Attach your gear to the Clamp Lock, ensuring it is properly secured.
- If using with MOLLE systems, ensure compatibility and secure integration.
- Regularly check the stability and security of the attachment during use.

Disposal Instructions

- **Disposal:** Dispose of the OBI Clamp Lock in accordance with local regulations. Do not dispose of it in household waste.
- **Recycling:** If possible, recycle the materials according to local recycling programs.

Contact Information for Further Support

For any questions or concerns regarding the OBI Clamp Lock, please refer to the contact information provided by the retailer or manufacturer. They will be able to assist you with any inquiries about product safety or usage.

Thank you for choosing the OBI Clamp Lock. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk