

Flash Bang Pro Target Hit Indicator

Few things are more satisfying than hearing the ring of a successful hit on a steel target but at longer ranges or with multiple shooters knowing you hit the target can be nearly impossible. Get instant feedback and reassuring hit confirmation with the Flash Bang Pro. Featuring 10 ultra-bright LED lights that flash each time the target is impacted sending a visual hit confirmation back to the shooter at distances over 1 mile away. The Flash Bang Pro version features a multi position switch allowing the user to select a 1 second flash for competition where shooters may be engaging a target multiple times or a 6 second flash for longer-range uses where the long strobe is more desirable. Includes 3 AA batteries lasting over 30000 impacts and hook and loop material to attach the Flash Bang Pro to the back of almost any AR500 target 5 and larger. See what you have been hitting with the Caldwell Flash Bang Pro hit indicator. - Features - 10 ultra-bright LED lights visible at over 1 mile notify shooters of impacts - Adjustable flash time 1 sec. or 6 sec. for rapid-fire or long-range use - Low-impact energy detection works with rimfire and extreme ranges - Powered by 3 AA batteries (included) lasting over 30000 impacts - Versatile hook and loop attachment fits most AR500 targets 5 and larger

NO IMAGE
AVAILABLE

Attributes

- Name: [Flash Bang Pro Target Hit Indicator](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2014045
- Mfr. No.: 1215381
- Colour: Black
- Delivery weight: 0.23kg
- Shipping height: 222mm
- Shipping width: 212mm
- Shipping length: 44mm
- UPC: 198700000618

Table of Contents

- Startpage
- Flash Bang Pro Safety Instruction Guide
- About Us

Flash Bang Pro Safety Instruction Guide

Introduction

Thank you for choosing the Flash Bang Pro hit indicator for your AR500 targets. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure the Flash Bang Pro is used only in accordance with the manufacturer's instructions.
- Always handle the product with care to avoid damage.
- Keep the device out of reach of children and vulnerable groups to prevent accidents.
- Regularly inspect the Flash Bang Pro for any signs of wear or damage.
- If the device appears damaged or does not function correctly, discontinue use and seek assistance.
- Report any unsafe product experiences to local authorities.

Specific Safety Precautions for Use

- Use the Flash Bang Pro only with compatible AR500 targets that are 5 inches or larger.
- Ensure that the target area is clear of people and obstacles before shooting.
- Do not exceed the recommended distance of 1 mile for visibility of the LED lights.
- Be aware of your surroundings and ensure that no one is in the line of fire when using the Flash Bang Pro.
- Avoid using the device in adverse weather conditions, such as heavy rain or strong winds, that may affect its performance.
- Do not modify or attempt to repair the Flash Bang Pro yourself.

Instructions for Installation and Usage

1. Installation:

- Use the included hook and loop material to securely attach the Flash Bang Pro to the back of your AR500 target.
- Ensure that the device is mounted firmly to prevent it from falling during use.

2. Powering On:

- Insert the 3 AA batteries (included) into the Flash Bang Pro. Ensure the batteries are installed with the correct polarity.

3. Selecting Flash Time:

- Use the multiposition switch to select the desired flash time:
 - 1 second flash for rapidfire situations.
 - 6 second flash for longerrange use.

4. Using the Device:

- Aim and shoot at the target as you normally would. The Flash Bang Pro will activate and flash the LED lights upon impact.
- Observe the LED lights for instant hit confirmation.

5. After Use:

- Turn off the device when not in use to conserve battery life.

- Store the Flash Bang Pro in a dry place away from direct sunlight and extreme temperatures.

Disposal Instructions

- Dispose of the Flash Bang Pro and its components in accordance with local regulations.
- Remove batteries before disposal and recycle them at designated battery recycling locations.
- Do not dispose of the product in household waste.

Contact Information for Further Support

For additional support or inquiries regarding safety, please consult the manufacturer's website or contact your local distributor.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Flash Bang Pro!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk